




# PCB without Groundfilling



# PCB with Groundfilling




## Bare board rendered (F)






## Bare board rendered (B)




# Fab'ed board rendered (F)






B3603  
BST900  
B3806

Without probes




with lin and lout probes






D6008 with Vin, Iin and Iout probes




D6008 with Vin probe to A1





D6012 with Vin, Iin and Iout probes





D6012 with Vin probe to A1

