



B



A

B

A

LAYER 1



UNLESS OTHERWISE SPECIFIED, DIMENSIONS ARE IN MILLIMETERS ANGULAR = ± ° SURFACE FINISH  DO NOT SCALE DRAWING BREAK ALL SHARP EDGES AND REMOVE BURRS THIRD ANGLE PROJECTION 		NAME	DATE	TITLE		
	DRAWN	PAUL MYERS	06/24/2024			
	CHECKED					
	APPROVED					
				SIZE A		
	MATERIAL	FINISH		DWG NO.	REV.	
				SCALE 1:3	WEIGHT	SHEET 1 of 8


2

1

2

1

LAYER 2





2

1

2

1

ATTACH LAYER 1 & 2



Dowel - 3

Dowel - 4

Dowel - 17

Dowel - 9

Dowel - 18

Dowel - 19



2

1

2

1

LAYER 3






2

1

2

1

ATTACH LAYER 2 TO ASSEMBLY






2

1

2

1

LAYER 4




2

1

2

1

ATTACH LAYER 4 TO ASSEMBLY



Dowel - 1



Dowel - 7

Dowel - 6

Dowel - 21

Dowel - 15

Dowel - 23



2




1

2

1

Note: Before paneling, make sure the lightbulb socket is installed into the hole in part C-4.

Additionally make sure that at least 1 larger panel is affixed in a non permanent way so that you can remove it to change the lightbulb.



2

1