



For info on motor driving, see:  
<http://www.ermicro.com/blog/?p=706>



A diagram illustrating the Vdrive connections. A vertical bus labeled "Vdrive" at the top has an upward-pointing arrow. It connects to a series of 13 pins on the right side of a component. Each pin is connected to a specific input on a set of modules on the left:

- J1 CA
- J2 MA
- J3 MB
- J10 RL
- J11 RR
- J12 FOF
- J13 FOR

The modules on the left are labeled MOT\_A, MOT\_B, RAIL\_L, RAIL\_R, FOF\_SP, and FOR\_SP. Each module has a green line connecting it to the corresponding pin on the Vdrive bus, with a "1" indicating the connection point.



Sheet: /  
File: Wired-N-1A-2-1.kicad\_sch

**Title:**

Size: A4	Date:
KiCad E.D.A. kicad (6.0.1-0)	

Rev:  
Id: 1/1