



Step/Direction Driver Mode(SPI\_MODE=Open)  
 Standalone Mode(SPI\_MODE=GND)