
5. MAIN Electrical Parts List

SEC Code	Design LOC	Description
0401-001110	D5001	DIODE-SWITCHING
0404-001250	D5000	DIODE-SCHOTTKY
0406-001316	ZD6007	DIODE-TVS
0406-001413	ZD6008	DIODE-TVS
0406-001413	ZD6010	DIODE-TVS
0406-001413	ZD6013	DIODE-TVS
0406-001459	U6004	DIODE-TVS
0406-001459	ZD4000	DIODE-TVS
0406-001459	ZD6006	DIODE-TVS
0406-001459	ZD6009	DIODE-TVS
0406-001459	ZD6032	DIODE-TVS
0406-001465	ZD5006	DIODE-TVS
0406-001465	ZD5007	DIODE-TVS
0406-001465	ZD6900	DIODE-TVS
0406-001465	ZD6901	DIODE-TVS
0406-001505	ZD6001	DIODE-TVS
0406-001592	ZD4001	DIODE-TVS
0406-001592	ZD4002	DIODE-TVS
0406-001592	ZD4003	DIODE-TVS
0406-001592	ZD4004	DIODE-TVS
0406-001592	ZD4005	DIODE-TVS
0406-001592	ZD4006	DIODE-TVS
0406-001592	ZD4007	DIODE-TVS
0406-001592	ZD4008	DIODE-TVS
0406-001592	ZD6018	DIODE-TVS
0406-001592	ZD7008	DIODE-TVS
0406-001592	ZD7009	DIODE-TVS
0406-001592	ZD7010	DIODE-TVS
0406-001592	ZD7011	DIODE-TVS
0406-001592	ZD7012	DIODE-TVS
0406-001633	D6000	DIODE-TVS
0406-001659	ZD4009	DIODE-TVS
0406-001659	ZD4010	DIODE-TVS
0406-001682	ZD1000	DIODE-TVS
0406-001682	ZD6012	DIODE-TVS
0406-001690	D6001	DIODE-TVS
0406-001690	D6002	DIODE-TVS
0406-001690	D6003	DIODE-TVS

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

0406-001690	D6004	DIODE-TVS
0406-001690	D6005	DIODE-TVS
0406-001690	ZD6016	DIODE-TVS
0406-001690	ZD6017	DIODE-TVS
0406-001717	ZD6023	DIODE-TVS
0406-001717	ZD6024	DIODE-TVS
0406-001717	ZD6025	DIODE-TVS
0406-001717	ZD6026	DIODE-TVS
0406-001728	ZD5003	DIODE-TVS
0406-001729	ZD6002	DIODE-TVS
0406-001729	ZD6005	DIODE-TVS
0406-001729	ZD6033	DIODE-TVS
0406-001729	ZD6034	DIODE-TVS
0406-001743	ZD6035	DIODE-TVS
0406-001743	ZD6036	DIODE-TVS
0406-001759	ZD6014	DIODE-TVS
0406-001759	ZD6015	DIODE-TVS
0406-001759	ZD6021	DIODE-TVS
0406-001759	ZD6022	DIODE-TVS
0406-001759	ZD6037	DIODE-TVS
0505-002088	TR6000	FET-SILICON
0505-003234	Q4000	FET-SILICON
0505-003529	Q5002	FET-SILICON
0601-003611	LED7000	LED
0903-002171	U4000	IC-MICROCONTROLLER
1001-001655	U3002	IC-ANALOG SWITCH
1001-001870	U2000	IC-RF SWITCH
1001-001949	U1008	IC-RF SWITCH
1001-001949	U1009	IC-RF SWITCH
1001-001964	U2004	IC-RF SWITCH
1001-001987	U1010	IC-RF SWITCH
1003-002805	U5012	IC-MOTOR DRIVER
1009-001066	U4005	IC-HALL EFFECT S/W
1009-001066	U4006	IC-HALL EFFECT S/W
1105-002855	U3001UP	IC-DDR4 SDRAM
1107-002512	UME3000	IC-EMMC
1201-003719	U1007	IC-IF/RF AMP
1201-003786	U4008	IC-GPS AMP
1201-003975	U2002	IC-RF AMP

5. MAIN Electrical Parts List

1201-004099	U6014	IC-AUDIO AMP
1201-004106	PAM2000	IC-POWER AMP
1201-004107	PAM2001	IC-POWER AMP
1203-007884	U7005	IC-DC/DC CONVERTER
1203-007890	U7006	IC-POSI.FIXED REG.
1203-007890	U7017	IC-POSI.FIXED REG.
1203-008249	U4007	IC-POSI.FIXED REG.
1203-008249	U5013	IC-POSI.FIXED REG.
1203-008475	U6010	IC-VOL. DETECTOR
1203-008490	U6015	IC-POSI.FIXED REG.
1203-008693	U1003	IC-DC/DC CONVERTER
1203-008696	U7015	IC-DC/DC CONVERTER
1203-008719	U4011	IC-MULTI REG.
1203-008850	U4004	IC-DC/DC CONVERTER
1203-008864	U7007	IC-POSI.FIXED REG.
1203-008865	U7000	IC-POSI.FIXED REG.
1203-008865	U7003	IC-POSI.FIXED REG.
1203-008867	U4010	IC-POSI.FIXED REG.
1203-008867	U4015	IC-POSI.FIXED REG.
1203-008867	U4016	IC-POSI.FIXED REG.
1203-008872	U5011	IC-POSI.FIXED REG.
1203-008883	U5007	IC-POWER SUPERVISOR
1203-008904	U5005	IC-POWER SUPERVISOR
1204-003365	U4009	IC-TUNER
1205-005564	U4002	IC-WIFI
1205-005639	U2001	IC-TRANSCIEVER
1205-005680	U4012	IC-NFC/RFID
1205-005701	U3001	IC-MODEM
1205-005712	U6011	IC-TOUCH
1209-002294	U4001	IC-PRESSURE SENSOR
1209-002344	U4003	IC-ACCEL./GYRO SENSOR
1209-002401	U4014	IC-MAGNETIC SENSOR
1404-001664	TH5000	THERMISTOR-NTC
1404-001724	TH3000	THERMISTOR-NTC
1404-001724	TH3001	THERMISTOR-NTC
1404-001724	V5000	THERMISTOR-NTC
1404-001734	U2003	THERMISTOR-NTC
1405-001183	VR6004	VARISTOR
1405-001183	VR6005	VARISTOR

5. MAIN Electrical Parts List

1405-001395	VR2005	VARISTOR
1405-001404	VR7004	VARISTOR
1405-001404	VR7005	VARISTOR
1405-001404	VR7006	VARISTOR
1405-001404	VR7007	VARISTOR
1405-001404	VR7008	VARISTOR
1405-001404	VR7009	VARISTOR
1405-001404	VR7010	VARISTOR
1405-001404	VR7011	VARISTOR
1405-001404	VR7012	VARISTOR
1405-001404	VR7013	VARISTOR
1405-001404	VR7014	VARISTOR
1405-001404	VR7015	VARISTOR
1405-001404	VR7016	VARISTOR
1405-001412	VR1003	VARISTOR
1405-001412	VR1006	VARISTOR
1405-001412	VR1008	VARISTOR
1405-001412	VR2000	VARISTOR
1405-001412	VR2001	VARISTOR
1405-001412	VR2004	VARISTOR
1405-001412	VR2007	VARISTOR
1405-001412	VR2008	VARISTOR
1405-001412	VR4002	VARISTOR
1405-001412	VR4010	VARISTOR
1405-001412	VR6000	VARISTOR
1405-001412	VR6001	VARISTOR
1405-001412	VR6002	VARISTOR
1405-001412	VR6003	VARISTOR
1405-001412	VR6006	VARISTOR
1405-001412	VR6007	VARISTOR
1405-001412	VR6008	VARISTOR
1405-001416	VR1002	VARISTOR
1405-001416	VR1009	VARISTOR
1405-001420	VR2002	VARISTOR
1405-001420	VR2101	VARISTOR
1405-001420	VR2102	VARISTOR
1405-001420	VR2103	VARISTOR
1405-001420	VR2104	VARISTOR
1405-001425	VR1001	VARISTOR

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

1405-001434	VR2006	VARISTOR
2007-000172	R5036	R-CHIP
2007-001295	R6048	R-CHIP
2007-001305	R6062	R-CHIP
2007-002796	L6023	R-CHIP
2007-002970	R6049	R-CHIP
2007-003015	R6052	R-CHIP
2007-003015	R6053	R-CHIP
2007-007092	R6058	R-CHIP
2007-007092	R6901	R-CHIP
2007-007142	R5024	R-CHIP
2007-007190	R6029	R-CHIP
2007-007190	R6030	R-CHIP
2007-007405	R1901	R-CHIP
2007-007589	R6019	R-CHIP
2007-007671	R7008	R-CHIP
2007-007741	R2005	R-CHIP
2007-007741	R3011	R-CHIP
2007-007741	R3015	R-CHIP
2007-007741	R3018	R-CHIP
2007-007741	R3019	R-CHIP
2007-007741	R3030	R-CHIP
2007-007741	R3049	R-CHIP
2007-007741	R3053	R-CHIP
2007-007741	R3055	R-CHIP
2007-007741	R4008	R-CHIP
2007-007741	R4010	R-CHIP
2007-007741	R4014	R-CHIP
2007-007741	R4015	R-CHIP
2007-007741	R4025	R-CHIP
2007-007741	R4035	R-CHIP
2007-007741	R4041	R-CHIP
2007-007741	R4043	R-CHIP
2007-007741	R5800	R-CHIP
2007-007741	R5911	R-CHIP
2007-007741	R5912	R-CHIP
2007-007741	R6027	R-CHIP
2007-007741	R6028	R-CHIP
2007-007741	R6042	R-CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2007-007741	R6047	R-CHIP
2007-007741	R7007	R-CHIP
2007-007860	R4801	R-CHIP
2007-007861	R4802	R-CHIP
2007-007942	R5022	R-CHIP
2007-007946	R5023	R-CHIP
2007-008043	R2000	R-CHIP
2007-008044	R4017	R-CHIP
2007-008044	R4018	R-CHIP
2007-008044	R4019	R-CHIP
2007-008044	R4022	R-CHIP
2007-008044	R4049	R-CHIP
2007-008044	R4052	R-CHIP
2007-008056	R1001	R-CHIP
2007-008056	R1002	R-CHIP
2007-008117	R5013	R-CHIP
2007-008210	R6012	R-CHIP
2007-008420	R3931	R-CHIP
2007-008531	R5913	R-CHIP
2007-008531	R7020	R-CHIP
2007-008531	R7021	R-CHIP
2007-008587	R4030	R-CHIP
2007-008587	R6054	R-CHIP
2007-008587	R6056	R-CHIP
2007-008587	R6057	R-CHIP
2007-008785	R1000	R-CHIP
2007-008811	R4000	R-CHIP
2007-009111	R3020	R-CHIP
2007-009111	R4042	R-CHIP
2007-009157	R3026	R-CHIP
2007-009157	R3045	R-CHIP
2007-009157	R4001	R-CHIP
2007-009157	R4026	R-CHIP
2007-009157	R5019	R-CHIP
2007-009157	R5030	R-CHIP
2007-009157	R6031	R-CHIP
2007-009157	R6033	R-CHIP
2007-009158	R5007	R-CHIP
2007-009171	R3010	R-CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2007-009171	R3014	R-CHIP
2007-009171	R5029	R-CHIP
2007-009201	R6000	R-CHIP
2007-009201	R6006	R-CHIP
2007-009212	R5005	R-CHIP
2007-009212	R5009	R-CHIP
2007-009212	R5040	R-CHIP
2007-009212	R6014	R-CHIP
2007-009314	R6005	R-CHIP
2007-009314	R6065	R-CHIP
2007-009315	R6101	R-CHIP
2007-009315	R6102	R-CHIP
2007-009315	R6103	R-CHIP
2007-009315	R6104	R-CHIP
2007-009315	R6201	R-CHIP
2007-009315	R6202	R-CHIP
2007-009315	R6203	R-CHIP
2007-009315	R6204	R-CHIP
2007-009352	R4005	R-CHIP
2007-009352	R4007	R-CHIP
2007-009352	R4034	R-CHIP
2007-009352	R5035	R-CHIP
2007-009352	R6066	R-CHIP
2007-009352	R7012	R-CHIP
2007-009402	R4031	R-CHIP
2007-009408	R3016	R-CHIP
2007-009408	R3017	R-CHIP
2007-009408	R3021	R-CHIP
2007-009408	R3022	R-CHIP
2007-009408	R3023	R-CHIP
2007-009408	R3024	R-CHIP
2007-009408	R3027	R-CHIP
2007-009408	R3028	R-CHIP
2007-009408	R3033	R-CHIP
2007-009408	R3034	R-CHIP
2007-009408	R3047	R-CHIP
2007-009408	R3048	R-CHIP
2007-009408	R3901	R-CHIP
2007-009408	R3902	R-CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2007-009408	R4002	R-CHIP
2007-009408	R4003	R-CHIP
2007-009408	R4004	R-CHIP
2007-009408	R4006	R-CHIP
2007-009408	R4027	R-CHIP
2007-009408	R4028	R-CHIP
2007-009408	R4039	R-CHIP
2007-009408	R6015	R-CHIP
2007-009408	R6043	R-CHIP
2007-009408	R6044	R-CHIP
2007-009408	R6045	R-CHIP
2007-009410	R6020	R-CHIP
2007-009801	R5025	R-CHIP
2007-009801	R6040	R-CHIP
2007-009805	R1005	R-CHIP
2007-009805	R2001	R-CHIP
2007-009805	R4040	R-CHIP
2007-009920	R3000	R-CHIP
2007-009920	R3001	R-CHIP
2007-009920	R3003	R-CHIP
2007-009920	R3004	R-CHIP
2007-009969	R6016	R-CHIP
2007-010202	R4033	R-CHIP
2007-010202	R5033	R-CHIP
2007-010202	R5034	R-CHIP
2007-011043	R3005	R-CHIP
2007-011377	R6018	R-CHIP
2007-011648	R4044	R-CHIP
2007-011648	R4045	R-CHIP
2007-012038	R5008	R-CHIP
2007-012068	R5151	R-CHIP
2203-000233	C2002	C-CER,CHIP
2203-000254	C6025	C-CER,CHIP
2203-000489	C5098	C-CER,CHIP
2203-000489	C5099	C-CER,CHIP
2203-000812	C4093	C-CER,CHIP
2203-000995	C5211	C-CER,CHIP
2203-001153	C6038	C-CER,CHIP
2203-001153	C6046	C-CER,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-001153	C6049	C-CER,CHIP
2203-001239	C4088	C-CER,CHIP
2203-001239	C4096	C-CER,CHIP
2203-001239	C4116	C-CER,CHIP
2203-005682	C4057	C-CER,CHIP
2203-005682	C4085	C-CER,CHIP
2203-005682	C4100	C-CER,CHIP
2203-005682	C4115	C-CER,CHIP
2203-005682	C4117	C-CER,CHIP
2203-005682	C4118	C-CER,CHIP
2203-005682	C5117	C-CER,CHIP
2203-005682	C5121	C-CER,CHIP
2203-005682	C5123	C-CER,CHIP
2203-005682	C5201	C-CER,CHIP
2203-005682	C5202	C-CER,CHIP
2203-005682	C5203	C-CER,CHIP
2203-005682	C5204	C-CER,CHIP
2203-005682	C5205	C-CER,CHIP
2203-005682	C5206	C-CER,CHIP
2203-005682	C6014	C-CER,CHIP
2203-005682	C6022	C-CER,CHIP
2203-005682	C6028	C-CER,CHIP
2203-005682	C7010	C-CER,CHIP
2203-005682	C7089	C-CER,CHIP
2203-005719	C4122	C-CER,CHIP
2203-005725	C4071	C-CER,CHIP
2203-005727	C1024	C-CER,CHIP
2203-005727	C5118	C-CER,CHIP
2203-005727	C6050	C-CER,CHIP
2203-005729	C4086	C-CER,CHIP
2203-005729	C5061	C-CER,CHIP
2203-005729	C6002	C-CER,CHIP
2203-005729	C6012	C-CER,CHIP
2203-005729	C6020	C-CER,CHIP
2203-005729	C7011	C-CER,CHIP
2203-005729	C7027	C-CER,CHIP
2203-005729	C7034	C-CER,CHIP
2203-005729	C7037	C-CER,CHIP
2203-005729	C7203	C-CER,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-005731	C1070	C-CER,CHIP
2203-005731	C1071	C-CER,CHIP
2203-005731	C4124	C-CER,CHIP
2203-005731	C4125	C-CER,CHIP
2203-005731	C4800	C-CER,CHIP
2203-005731	C6032	C-CER,CHIP
2203-005731	C6033	C-CER,CHIP
2203-005732	C5210	C-CER,CHIP
2203-005732	C6001	C-CER,CHIP
2203-005732	C6055	C-CER,CHIP
2203-005734	C6030	C-CER,CHIP
2203-005734	C6031	C-CER,CHIP
2203-005734	C7026	C-CER,CHIP
2203-005734	C7031	C-CER,CHIP
2203-005734	C7039	C-CER,CHIP
2203-005736	C1000	C-CER,CHIP
2203-005736	C1002	C-CER,CHIP
2203-005736	C1006	C-CER,CHIP
2203-005736	C1013	C-CER,CHIP
2203-005736	C1015	C-CER,CHIP
2203-005736	C1018	C-CER,CHIP
2203-005736	C1019	C-CER,CHIP
2203-005736	C1025	C-CER,CHIP
2203-005736	C1027	C-CER,CHIP
2203-005736	C1029	C-CER,CHIP
2203-005736	C10291	C-CER,CHIP
2203-005736	C1032	C-CER,CHIP
2203-005736	C1033	C-CER,CHIP
2203-005736	C1084	C-CER,CHIP
2203-005736	C1089	C-CER,CHIP
2203-005736	C1093	C-CER,CHIP
2203-005736	C1099	C-CER,CHIP
2203-005736	C1100	C-CER,CHIP
2203-005736	C2007	C-CER,CHIP
2203-005736	C2023	C-CER,CHIP
2203-005736	C2085	C-CER,CHIP
2203-005736	C2091	C-CER,CHIP
2203-005736	C2096	C-CER,CHIP
2203-005736	C2097	C-CER,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-005736	C2099	C-CER,CHIP
2203-005736	C2101	C-CER,CHIP
2203-005736	C2106	C-CER,CHIP
2203-005736	C2107	C-CER,CHIP
2203-005736	C2111	C-CER,CHIP
2203-005736	C2115	C-CER,CHIP
2203-005736	C2116	C-CER,CHIP
2203-005736	C2120	C-CER,CHIP
2203-005736	C2125	C-CER,CHIP
2203-005736	C2142	C-CER,CHIP
2203-005736	C2145	C-CER,CHIP
2203-005736	C2162	C-CER,CHIP
2203-005736	C2999	C-CER,CHIP
2203-005736	C4022	C-CER,CHIP
2203-005736	C4040	C-CER,CHIP
2203-005736	C4041	C-CER,CHIP
2203-005736	C4062	C-CER,CHIP
2203-005736	C4099	C-CER,CHIP
2203-005736	C4101	C-CER,CHIP
2203-005736	C4111	C-CER,CHIP
2203-005736	C4121	C-CER,CHIP
2203-005736	C4199	C-CER,CHIP
2203-005736	L1003	C-CER,CHIP
2203-005736	L1026	C-CER,CHIP
2203-005736	L1065	C-CER,CHIP
2203-005736	L2022	C-CER,CHIP
2203-005740	C4058	C-CER,CHIP
2203-005777	C2018	C-CER,CHIP
2203-005777	C4066	C-CER,CHIP
2203-005777	L2076	C-CER,CHIP
2203-005789	C1014	C-CER,CHIP
2203-005789	C2051	C-CER,CHIP
2203-005789	C2061	C-CER,CHIP
2203-005789	C2063	C-CER,CHIP
2203-005789	C2066	C-CER,CHIP
2203-005789	C2086	C-CER,CHIP
2203-005789	C2133	C-CER,CHIP
2203-005789	L2065	C-CER,CHIP
2203-005792	C2034	C-CER,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-005792	C2049	C-CER,CHIP
2203-005792	C2050	C-CER,CHIP
2203-005792	C6009	C-CER,CHIP
2203-005806	C10292	C-CER,CHIP
2203-005806	C1051	C-CER,CHIP
2203-005806	C2016	C-CER,CHIP
2203-005806	C2017	C-CER,CHIP
2203-005806	C2024	C-CER,CHIP
2203-005806	C2048	C-CER,CHIP
2203-005806	C2094	C-CER,CHIP
2203-005806	C2095	C-CER,CHIP
2203-006048	C4051	C-CER,CHIP
2203-006121	C6026	C-CER,CHIP
2203-006123	C1012	C-CER,CHIP
2203-006187	C1039	C-CER,CHIP
2203-006187	C1040	C-CER,CHIP
2203-006187	C2065	C-CER,CHIP
2203-006187	C2088	C-CER,CHIP
2203-006187	C2103	C-CER,CHIP
2203-006194	C2004	C-CER,CHIP
2203-006194	C6016	C-CER,CHIP
2203-006194	C6019	C-CER,CHIP
2203-006194	C6027	C-CER,CHIP
2203-006194	R6001	C-CER,CHIP
2203-006208	C4000	C-CER,CHIP
2203-006318	C2136	C-CER,CHIP
2203-006318	C6802	C-CER,CHIP
2203-006399	C4031	C-CER,CHIP
2203-006399	C4064	C-CER,CHIP
2203-006399	C7007	C-CER,CHIP
2203-006399	C7008	C-CER,CHIP
2203-006399	C7033	C-CER,CHIP
2203-006399	C7090	C-CER,CHIP
2203-006400	C1001	C-CER,CHIP
2203-006400	C1056	C-CER,CHIP
2203-006400	C1057	C-CER,CHIP
2203-006400	C2000	C-CER,CHIP
2203-006400	C2027	C-CER,CHIP
2203-006400	C2102	C-CER,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-006400	C4061	C-CER,CHIP
2203-006400	C5212	C-CER,CHIP
2203-006400	C6901	C-CER,CHIP
2203-006410	C2021	C-CER,CHIP
2203-006410	C2022	C-CER,CHIP
2203-006423	C1036	C-CER,CHIP
2203-006423	C2041	C-CER,CHIP
2203-006423	C2073	C-CER,CHIP
2203-006423	C3015	C-CER,CHIP
2203-006423	C3039	C-CER,CHIP
2203-006423	C4001	C-CER,CHIP
2203-006423	C4002	C-CER,CHIP
2203-006423	C4003	C-CER,CHIP
2203-006423	C4004	C-CER,CHIP
2203-006423	C4007	C-CER,CHIP
2203-006423	C4008	C-CER,CHIP
2203-006423	C4009	C-CER,CHIP
2203-006423	C4011	C-CER,CHIP
2203-006423	C4012	C-CER,CHIP
2203-006423	C4013	C-CER,CHIP
2203-006423	C4014	C-CER,CHIP
2203-006423	C4017	C-CER,CHIP
2203-006423	C4018	C-CER,CHIP
2203-006423	C4020	C-CER,CHIP
2203-006423	C4024	C-CER,CHIP
2203-006423	C4025	C-CER,CHIP
2203-006423	C4026	C-CER,CHIP
2203-006423	C4030	C-CER,CHIP
2203-006423	C4032	C-CER,CHIP
2203-006423	C4046	C-CER,CHIP
2203-006423	C4047	C-CER,CHIP
2203-006423	C4052	C-CER,CHIP
2203-006423	C4053	C-CER,CHIP
2203-006423	C4069	C-CER,CHIP
2203-006423	C5048	C-CER,CHIP
2203-006423	C5116	C-CER,CHIP
2203-006423	C6007	C-CER,CHIP
2203-006423	C6010	C-CER,CHIP
2203-006423	C6015	C-CER,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-006423	C6029	C-CER,CHIP
2203-006423	C6036	C-CER,CHIP
2203-006556	C2036	C-CER,CHIP
2203-006556	C2040	C-CER,CHIP
2203-006556	C2043	C-CER,CHIP
2203-006556	C6021	C-CER,CHIP
2203-006556	C6024	C-CER,CHIP
2203-006562	C4087	C-CER,CHIP
2203-006562	C5097	C-CER,CHIP
2203-006562	C5112	C-CER,CHIP
2203-006562	C5113	C-CER,CHIP
2203-006562	C5207	C-CER,CHIP
2203-006562	C7047	C-CER,CHIP
2203-006562	C7049	C-CER,CHIP
2203-006642	C4084	C-CER,CHIP
2203-006648	C4070	C-CER,CHIP
2203-006665	C2032	C-CER,CHIP
2203-006665	C4049	C-CER,CHIP
2203-006665	C4068	C-CER,CHIP
2203-006668	C2001	C-CER,CHIP
2203-006668	C2003	C-CER,CHIP
2203-006668	C3000	C-CER,CHIP
2203-006668	C3001	C-CER,CHIP
2203-006707	C4060	C-CER,CHIP
2203-006824	C5041	C-CER,CHIP
2203-006839	C2037	C-CER,CHIP
2203-006839	C2118	C-CER,CHIP
2203-006839	C5050	C-CER,CHIP
2203-006839	C5052	C-CER,CHIP
2203-006839	C5077	C-CER,CHIP
2203-006846	C2025	C-CER,CHIP
2203-006846	C2035	C-CER,CHIP
2203-006846	C2057	C-CER,CHIP
2203-006872	C4023	C-CER,CHIP
2203-006872	C4034	C-CER,CHIP
2203-006872	C5018	C-CER,CHIP
2203-006872	C5025	C-CER,CHIP
2203-006872	C5026	C-CER,CHIP
2203-006872	C6035	C-CER,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-006872	C7009	C-CER,CHIP
2203-006896	C2009	C-CER,CHIP
2203-006896	C2160	C-CER,CHIP
2203-006896	C2161	C-CER,CHIP
2203-006978	C6043	C-CER,CHIP
2203-006979	C2068	C-CER,CHIP
2203-006979	C2070	C-CER,CHIP
2203-006979	C2075	C-CER,CHIP
2203-006979	C2076	C-CER,CHIP
2203-006979	C2078	C-CER,CHIP
2203-006979	C2080	C-CER,CHIP
2203-006979	C2152	C-CER,CHIP
2203-006979	C2154	C-CER,CHIP
2203-006979	C6023	C-CER,CHIP
2203-007194	C2015	C-CER,CHIP
2203-007194	C2148	C-CER,CHIP
2203-007210	C3040	C-CER,CHIP
2203-007271	C5039	C-CER,CHIP
2203-007271	C5095	C-CER,CHIP
2203-007271	C5111	C-CER,CHIP
2203-007279	C4033	C-CER,CHIP
2203-007279	C5107	C-CER,CHIP
2203-007279	C6017	C-CER,CHIP
2203-007279	C6900	C-CER,CHIP
2203-007279	C7030	C-CER,CHIP
2203-007279	C7041	C-CER,CHIP
2203-007279	C7042	C-CER,CHIP
2203-007279	C7043	C-CER,CHIP
2203-007279	C7082	C-CER,CHIP
2203-007279	C7083	C-CER,CHIP
2203-007279	C7084	C-CER,CHIP
2203-007279	C7091	C-CER,CHIP
2203-007279	C7621	C-CER,CHIP
2203-007279	C7622	C-CER,CHIP
2203-007279	C7635	C-CER,CHIP
2203-007295	C2126	C-CER,CHIP
2203-007317	C3006	C-CER,CHIP
2203-007317	C3024	C-CER,CHIP
2203-007317	C3038	C-CER,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-007317	C3041	C-CER,CHIP
2203-007317	C3104	C-CER,CHIP
2203-007317	C4016	C-CER,CHIP
2203-007317	C4120	C-CER,CHIP
2203-007317	C5002	C-CER,CHIP
2203-007317	C5003	C-CER,CHIP
2203-007317	C5004	C-CER,CHIP
2203-007317	C5024	C-CER,CHIP
2203-007317	C6011	C-CER,CHIP
2203-007317	C6903	C-CER,CHIP
2203-007391	C2072	C-CER,CHIP
2203-007392	C5036	C-CER,CHIP
2203-007392	C5044	C-CER,CHIP
2203-007392	C5096	C-CER,CHIP
2203-007393	C5042	C-CER,CHIP
2203-007393	C5051	C-CER,CHIP
2203-007393	C5054	C-CER,CHIP
2203-007393	C5055	C-CER,CHIP
2203-007393	C5066	C-CER,CHIP
2203-007393	C5070	C-CER,CHIP
2203-007393	C5071	C-CER,CHIP
2203-007449	C1064	C-CER,CHIP
2203-007449	C3002	C-CER,CHIP
2203-007449	C3003	C-CER,CHIP
2203-007449	C3004	C-CER,CHIP
2203-007449	C3005	C-CER,CHIP
2203-007449	C3007	C-CER,CHIP
2203-007449	C3008	C-CER,CHIP
2203-007449	C3009	C-CER,CHIP
2203-007449	C3010	C-CER,CHIP
2203-007449	C3011	C-CER,CHIP
2203-007449	C3012	C-CER,CHIP
2203-007449	C3014	C-CER,CHIP
2203-007449	C3016	C-CER,CHIP
2203-007449	C3017	C-CER,CHIP
2203-007449	C3018	C-CER,CHIP
2203-007449	C3019	C-CER,CHIP
2203-007449	C3020	C-CER,CHIP
2203-007449	C3021	C-CER,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-007449	C3026	C-CER,CHIP
2203-007449	C3027	C-CER,CHIP
2203-007449	C3028	C-CER,CHIP
2203-007449	C3029	C-CER,CHIP
2203-007449	C3030	C-CER,CHIP
2203-007449	C3031	C-CER,CHIP
2203-007449	C3032	C-CER,CHIP
2203-007449	C3033	C-CER,CHIP
2203-007449	C3036	C-CER,CHIP
2203-007449	C3037	C-CER,CHIP
2203-007449	C3042	C-CER,CHIP
2203-007449	C3052	C-CER,CHIP
2203-007449	C3053	C-CER,CHIP
2203-007449	C3054	C-CER,CHIP
2203-007449	C3059	C-CER,CHIP
2203-007449	C3060	C-CER,CHIP
2203-007449	C3062	C-CER,CHIP
2203-007449	C3063	C-CER,CHIP
2203-007449	C3064	C-CER,CHIP
2203-007449	C3070	C-CER,CHIP
2203-007449	C3071	C-CER,CHIP
2203-007449	C3073	C-CER,CHIP
2203-007449	C3074	C-CER,CHIP
2203-007449	C3079	C-CER,CHIP
2203-007449	C3080	C-CER,CHIP
2203-007449	C3081	C-CER,CHIP
2203-007449	C3082	C-CER,CHIP
2203-007449	C3083	C-CER,CHIP
2203-007449	C3084	C-CER,CHIP
2203-007449	C3093	C-CER,CHIP
2203-007449	C3097	C-CER,CHIP
2203-007449	C3098	C-CER,CHIP
2203-007449	C3099	C-CER,CHIP
2203-007449	C3100	C-CER,CHIP
2203-007449	C3101	C-CER,CHIP
2203-007449	C3105	C-CER,CHIP
2203-007449	C3106	C-CER,CHIP
2203-007449	C4005	C-CER,CHIP
2203-007449	C4006	C-CER,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-007449	C4010	C-CER,CHIP
2203-007449	C4015	C-CER,CHIP
2203-007449	C4019	C-CER,CHIP
2203-007449	C4021	C-CER,CHIP
2203-007449	C4027	C-CER,CHIP
2203-007449	C4028	C-CER,CHIP
2203-007449	C4029	C-CER,CHIP
2203-007449	C4055	C-CER,CHIP
2203-007449	C4073	C-CER,CHIP
2203-007449	C4074	C-CER,CHIP
2203-007449	C4079	C-CER,CHIP
2203-007449	C4081	C-CER,CHIP
2203-007449	C4082	C-CER,CHIP
2203-007449	C4083	C-CER,CHIP
2203-007449	C4091	C-CER,CHIP
2203-007449	C4092	C-CER,CHIP
2203-007449	C4094	C-CER,CHIP
2203-007449	C4128	C-CER,CHIP
2203-007449	C4913	C-CER,CHIP
2203-007449	C5000	C-CER,CHIP
2203-007449	C5001	C-CER,CHIP
2203-007449	C5005	C-CER,CHIP
2203-007449	C5006	C-CER,CHIP
2203-007449	C5007	C-CER,CHIP
2203-007449	C5008	C-CER,CHIP
2203-007449	C5009	C-CER,CHIP
2203-007449	C5010	C-CER,CHIP
2203-007449	C5011	C-CER,CHIP
2203-007449	C5012	C-CER,CHIP
2203-007449	C5013	C-CER,CHIP
2203-007449	C5014	C-CER,CHIP
2203-007449	C5015	C-CER,CHIP
2203-007449	C5016	C-CER,CHIP
2203-007449	C5017	C-CER,CHIP
2203-007449	C5019	C-CER,CHIP
2203-007449	C5020	C-CER,CHIP
2203-007449	C5021	C-CER,CHIP
2203-007449	C5022	C-CER,CHIP
2203-007449	C5023	C-CER,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-007449	C5027	C-CER,CHIP
2203-007449	C5028	C-CER,CHIP
2203-007449	C5029	C-CER,CHIP
2203-007449	C5030	C-CER,CHIP
2203-007449	C5031	C-CER,CHIP
2203-007449	C5032	C-CER,CHIP
2203-007449	C5033	C-CER,CHIP
2203-007449	C5056	C-CER,CHIP
2203-007449	C5085	C-CER,CHIP
2203-007449	C5086	C-CER,CHIP
2203-007449	C5087	C-CER,CHIP
2203-007449	C5088	C-CER,CHIP
2203-007449	C5089	C-CER,CHIP
2203-007449	C5090	C-CER,CHIP
2203-007449	C5091	C-CER,CHIP
2203-007449	C5092	C-CER,CHIP
2203-007449	C5114	C-CER,CHIP
2203-007449	C5208	C-CER,CHIP
2203-007449	C5801	C-CER,CHIP
2203-007449	C7014	C-CER,CHIP
2203-007449	C7015	C-CER,CHIP
2203-007449	C7017	C-CER,CHIP
2203-007449	C7022	C-CER,CHIP
2203-007449	C7044	C-CER,CHIP
2203-007449	C7045	C-CER,CHIP
2203-007449	C7046	C-CER,CHIP
2203-007449	C7048	C-CER,CHIP
2203-007449	C7062	C-CER,CHIP
2203-007449	C7063	C-CER,CHIP
2203-007449	C7064	C-CER,CHIP
2203-007474	C3043	C-CER,CHIP
2203-007474	C3057	C-CER,CHIP
2203-007474	C3069	C-CER,CHIP
2203-007474	C3086	C-CER,CHIP
2203-007474	C7005	C-CER,CHIP
2203-007474	C7006	C-CER,CHIP
2203-007474	C7088	C-CER,CHIP
2203-007503	C5049	C-CER,CHIP
2203-007503	C5059	C-CER,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-007503	C5060	C-CER,CHIP
2203-007634	C5037	C-CER,CHIP
2203-007775	C1065	C-CER,CHIP
2203-007775	C2019	C-CER,CHIP
2203-007775	C2020	C-CER,CHIP
2203-007775	C5082	C-CER,CHIP
2203-007795	C2069	C-CER,CHIP
2203-007795	C2077	C-CER,CHIP
2203-007795	C2081	C-CER,CHIP
2203-007795	C2083	C-CER,CHIP
2203-007795	C4119	C-CER,CHIP
2203-007796	C2011	C-CER,CHIP
2203-007796	C2059	C-CER,CHIP
2203-007796	C2067	C-CER,CHIP
2203-007796	C2074	C-CER,CHIP
2203-007796	C2079	C-CER,CHIP
2203-007796	C2082	C-CER,CHIP
2203-007796	C4090	C-CER,CHIP
2203-007796	C6054	C-CER,CHIP
2203-008094	C6041	C-CER,CHIP
2203-008097	C2042	C-CER,CHIP
2203-008097	C2044	C-CER,CHIP
2203-008097	C3022	C-CER,CHIP
2203-008097	C3023	C-CER,CHIP
2203-008097	C3025	C-CER,CHIP
2203-008097	C5101	C-CER,CHIP
2203-008097	C5105	C-CER,CHIP
2203-008097	C5106	C-CER,CHIP
2203-008097	C6003	C-CER,CHIP
2203-008097	C6006	C-CER,CHIP
2203-008158	C5057	C-CER,CHIP
2203-008158	C5063	C-CER,CHIP
2203-008242	C4072	C-CER,CHIP
2203-008242	C5093	C-CER,CHIP
2203-008242	C5100	C-CER,CHIP
2203-008242	C5122	C-CER,CHIP
2203-008312	C5034	C-CER,CHIP
2203-008312	C5067	C-CER,CHIP
2203-008312	C5072	C-CER,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-008312	C5075	C-CER,CHIP
2203-008312	C5081	C-CER,CHIP
2203-008312	C5083	C-CER,CHIP
2203-008394	C1072	C-CER,CHIP
2203-008529	C4050	C-CER,CHIP
2203-008529	C6904	C-CER,CHIP
2203-008529	C7012	C-CER,CHIP
2203-008529	C7013	C-CER,CHIP
2203-008654	C6039	C-CER,CHIP
2203-008654	C6040	C-CER,CHIP
2203-008654	C6042	C-CER,CHIP
2203-008860	C4054	C-CER,CHIP
2203-008860	C4078	C-CER,CHIP
2203-008860	C4080	C-CER,CHIP
2203-008860	C4127	C-CER,CHIP
2203-008860	C4912	C-CER,CHIP
2203-008860	C5084	C-CER,CHIP
2203-008860	C5102	C-CER,CHIP
2203-008860	C7016	C-CER,CHIP
2203-008860	C7020	C-CER,CHIP
2203-008860	C7065	C-CER,CHIP
2203-008876	C2038	C-CER,CHIP
2203-009049	C5115	C-CER,CHIP
2203-009167	C4089	C-CER,CHIP
2203-009167	C4097	C-CER,CHIP
2203-009618	C5043	C-CER,CHIP
2203-009733	C1063	C-CER,CHIP
2203-009733	C2045	C-CER,CHIP
2203-009733	C4045	C-CER,CHIP
2203-009733	C4076	C-CER,CHIP
2203-009733	C5040	C-CER,CHIP
2203-009733	C5045	C-CER,CHIP
2203-009733	C5046	C-CER,CHIP
2203-009733	C5047	C-CER,CHIP
2203-009733	C5053	C-CER,CHIP
2203-009733	C5058	C-CER,CHIP
2203-009733	C5062	C-CER,CHIP
2203-009733	C5213	C-CER,CHIP
2203-009733	C5214	C-CER,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-009733	C6008	C-CER,CHIP
2203-009733	C6018	C-CER,CHIP
2203-009733	C7032	C-CER,CHIP
2203-009733	C7035	C-CER,CHIP
2203-009733	C7036	C-CER,CHIP
2203-009733	C7081	C-CER,CHIP
2203-009733	C7619	C-CER,CHIP
2203-009733	C7620	C-CER,CHIP
2203-009734	C4035	C-CER,CHIP
2409-001369	TA5000	C-POLYMER ,CHIP
2409-001369	TA5001	C-POLYMER ,CHIP
2703-002900	L6003	INDUCTOR-SMD
2703-002901	C1054	INDUCTOR-SMD
2703-002901	C2058	INDUCTOR-SMD
2703-002901	C2140	INDUCTOR-SMD
2703-002901	C2141	INDUCTOR-SMD
2703-002901	L1007	INDUCTOR-SMD
2703-002901	L1024	INDUCTOR-SMD
2703-002901	L1027	INDUCTOR-SMD
2703-002901	L1028	INDUCTOR-SMD
2703-002901	L2005	INDUCTOR-SMD
2703-002901	L2079	INDUCTOR-SMD
2703-002907	C2105	INDUCTOR-SMD
2703-002907	L1021	INDUCTOR-SMD
2703-002907	L2014	INDUCTOR-SMD
2703-002907	L2016	INDUCTOR-SMD
2703-002907	L2021	INDUCTOR-SMD
2703-002907	L2028	INDUCTOR-SMD
2703-002907	L2038	INDUCTOR-SMD
2703-002907	L2060	INDUCTOR-SMD
2703-002907	L4024	INDUCTOR-SMD
2703-002951	L4004	INDUCTOR-SMD
2703-002951	L4005	INDUCTOR-SMD
2703-002953	C2030	INDUCTOR-SMD
2703-002953	C2062	INDUCTOR-SMD
2703-002953	L6022	INDUCTOR-SMD
2703-002958	L1002	INDUCTOR-SMD
2703-002959	L4020	INDUCTOR-SMD
2703-002960	L1020	INDUCTOR-SMD

5. MAIN Electrical Parts List

2703-002960	L1025	INDUCTOR-SMD
2703-002960	L1067	INDUCTOR-SMD
2703-002960	L2006	INDUCTOR-SMD
2703-002960	L2901	INDUCTOR-SMD
2703-002960	L6016	INDUCTOR-SMD
2703-002960	L6017	INDUCTOR-SMD
2703-002960	L6018	INDUCTOR-SMD
2703-002960	L6019	INDUCTOR-SMD
2703-002960	L6020	INDUCTOR-SMD
2703-002960	L6021	INDUCTOR-SMD
2703-002999	C2158	INDUCTOR-SMD
2703-002999	L1029	INDUCTOR-SMD
2703-003004	L4999	INDUCTOR-SMD
2703-003121	L4016	INDUCTOR-SMD
2703-003121	L4021	INDUCTOR-SMD
2703-003121	L4022	INDUCTOR-SMD
2703-003293	L1017	INDUCTOR-SMD
2703-003878	L6014	INDUCTOR-SMD
2703-003970	C4065	INDUCTOR-SMD
2703-004000	L2027	INDUCTOR-SMD
2703-004001	L1063	INDUCTOR-SMD
2703-004012	L1004	INDUCTOR-SMD
2703-004012	L2011	INDUCTOR-SMD
2703-004013	C2033	INDUCTOR-SMD
2703-004013	C2054	INDUCTOR-SMD
2703-004013	C2139	INDUCTOR-SMD
2703-004013	L2002	INDUCTOR-SMD
2703-004013	L2004	INDUCTOR-SMD
2703-004013	L2009	INDUCTOR-SMD
2703-004013	L2043	INDUCTOR-SMD
2703-004013	L2077	INDUCTOR-SMD
2703-004013	L2080	INDUCTOR-SMD
2703-004014	C2005	INDUCTOR-SMD
2703-004018	C2047	INDUCTOR-SMD
2703-004018	L2025	INDUCTOR-SMD
2703-004018	L2051	INDUCTOR-SMD
2703-004018	L2063	INDUCTOR-SMD
2703-004032	L2012	INDUCTOR-SMD
2703-004033	L2013	INDUCTOR-SMD

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2703-004034	C1052	INDUCTOR-SMD
2703-004034	C4048	INDUCTOR-SMD
2703-004034	L2045	INDUCTOR-SMD
2703-004035	L1015	INDUCTOR-SMD
2703-004035	L1019	INDUCTOR-SMD
2703-004035	L2049	INDUCTOR-SMD
2703-004035	L2052	INDUCTOR-SMD
2703-004036	C1016	INDUCTOR-SMD
2703-004036	L2047	INDUCTOR-SMD
2703-004036	L2056	INDUCTOR-SMD
2703-004036	L2062	INDUCTOR-SMD
2703-004037	L1011	INDUCTOR-SMD
2703-004037	L2019	INDUCTOR-SMD
2703-004038	C1005	INDUCTOR-SMD
2703-004038	C2090	INDUCTOR-SMD
2703-004038	L1010	INDUCTOR-SMD
2703-004038	L1016	INDUCTOR-SMD
2703-004259	L2008	INDUCTOR-SMD
2703-004286	C2029	INDUCTOR-SMD
2703-004286	L1000	INDUCTOR-SMD
2703-004286	L2050	INDUCTOR-SMD
2703-004286	L2070	INDUCTOR-SMD
2703-004288	L2023	INDUCTOR-SMD
2703-004289	L2001	INDUCTOR-SMD
2703-004289	L2042	INDUCTOR-SMD
2703-004289	L2054	INDUCTOR-SMD
2703-004289	L2064	INDUCTOR-SMD
2703-004297	L7003	INDUCTOR-SMD
2703-004299	L4003	INDUCTOR-SMD
2703-004300	C2031	INDUCTOR-SMD
2703-004301	C1009	INDUCTOR-SMD
2703-004301	C1010	INDUCTOR-SMD
2703-004301	C1034	INDUCTOR-SMD
2703-004301	C2098	INDUCTOR-SMD
2703-004301	C2104	INDUCTOR-SMD
2703-004301	L2040	INDUCTOR-SMD
2703-004302	L1001	INDUCTOR-SMD
2703-004302	L2018	INDUCTOR-SMD
2703-004317	L1055	INDUCTOR-SMD

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2703-004328	L2020	INDUCTOR-SMD
2703-004362	C2159	INDUCTOR-SMD
2703-004363	L1022	INDUCTOR-SMD
2703-004366	C2092	INDUCTOR-SMD
2703-004366	L4015	INDUCTOR-SMD
2703-004367	C1020	INDUCTOR-SMD
2703-004369	C1022	INDUCTOR-SMD
2703-004369	L2024	INDUCTOR-SMD
2703-004369	L2046	INDUCTOR-SMD
2703-004764	C2046	INDUCTOR-SMD
2703-004862	L1014	INDUCTOR-SMD
2703-005017	L4000	INDUCTOR-SMD
2703-005066	L1051	INDUCTOR-SMD
2703-005066	L6002	INDUCTOR-SMD
2703-005067	L5004	INDUCTOR-SMD
2703-005067	L5008	INDUCTOR-SMD
2703-005067	L5009	INDUCTOR-SMD
2703-005085	C2055	INDUCTOR-SMD
2703-005085	L2026	INDUCTOR-SMD
2703-005085	L2030	INDUCTOR-SMD
2703-005085	L2031	INDUCTOR-SMD
2703-005085	L2041	INDUCTOR-SMD
2703-005087	C2134	INDUCTOR-SMD
2703-005087	C2135	INDUCTOR-SMD
2703-005087	L2017	INDUCTOR-SMD
2703-005087	L2053	INDUCTOR-SMD
2703-005136	L5006	INDUCTOR-SMD
2703-005200	L4006	INDUCTOR-SMD
2703-005418	L7101	INDUCTOR-SMD
2703-005419	L7007	INDUCTOR-SMD
2703-005419	L7008	INDUCTOR-SMD
2703-005581	L5003	INDUCTOR-SMD
2703-005581	L5007	INDUCTOR-SMD
2801-005254	OSC5000	CRYSTAL-SMD
2801-005323	OSC4000	CRYSTAL-SMD
2805-001113	OSC4010	OSCILLATOR-TCXO
2809-001411	TCX2000	OSCILLATOR-VCTCXO
2901-001690	C3013	FILTER-EMI SMD
2901-001690	C3034	FILTER-EMI SMD

5. MAIN Electrical Parts List

2901-001690	C3035	FILTER-EMI SMD
2901-001690	C3046	FILTER-EMI SMD
2901-001690	C3047	FILTER-EMI SMD
2901-001690	C3072	FILTER-EMI SMD
2901-001690	C3107	FILTER-EMI SMD
2901-001690	C3108	FILTER-EMI SMD
2901-001690	C3109	FILTER-EMI SMD
2901-001690	C3110	FILTER-EMI SMD
2901-001690	C3111	FILTER-EMI SMD
2901-001690	C3112	FILTER-EMI SMD
2901-001690	C3113	FILTER-EMI SMD
2901-001798	F7010	FILTER-EMI/ESD
2901-001798	F7011	FILTER-EMI/ESD
2901-001798	F7012	FILTER-EMI/ESD
2901-001798	F7013	FILTER-EMI/ESD
2901-001798	F7014	FILTER-EMI/ESD
2904-002257	F2006	FILTER-SAW
2904-002269	F2001	FILTER-SAW
2904-002314	F4000	FILTER-SAW
2904-002326	F2002	FILTER-SAW
2904-002349	F2007	FILTER-SAW
2904-002350	F2008	FILTER-SAW
2904-002355	F4002	FILTER-SAW
2904-002361	F2000	FILTER-SAW
2904-002365	F2009	FILTER-SAW
2910-000365	F1004	DUPLEXER-SAW
2910-000390	F2004	DUPLEXER-SAW
2911-000414	U1006	DUPLEXER-FEM
2911-000435	U2005	DUPLEXER-ASM
3003-001233	MIC6000	MIC MEMS
3003-001233	MIC6001	MIC MEMS
3301-001438	L6008	BEAD-SMD
3301-001885	L6009	BEAD-SMD
3301-001885	L6010	BEAD-SMD
3301-001885	L6011	BEAD-SMD
3301-002078	L6000	BEAD-SMD
3301-002078	L6001	BEAD-SMD
3301-002078	L6006	BEAD-SMD
3301-002078	L6012	BEAD-SMD

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

3301-002078	L6013	BEAD-SMD
3301-002078	L6032	BEAD-SMD
3301-002122	L1045	BEAD-SMD
3301-002122	L1046	BEAD-SMD
3301-002122	L6004	BEAD-SMD
3301-002122	L6005	BEAD-SMD
3301-002122	L6033	BEAD-SMD
3301-002223	L7000	BEAD-SMD
3301-002223	L7001	BEAD-SMD
3301-002236	L3001	BEAD-SMD
3301-002236	L4011	BEAD-SMD
3301-002236	L4012	BEAD-SMD
3301-002237	L1050	BEAD-SMD
3301-002237	L1072	BEAD-SMD
3301-002237	L2010	BEAD-SMD
3301-002237	L2078	BEAD-SMD
3301-002237	L4014	BEAD-SMD
3301-002238	L2035	BEAD-SMD
3301-002238	L2036	BEAD-SMD
3301-002238	L2039	BEAD-SMD
3301-002238	L2057	BEAD-SMD
3301-002238	L4019	BEAD-SMD
3301-002243	L3000	BEAD-SMD
3301-002286	L4013	BEAD-SMD
3301-002286	L4017	BEAD-SMD
3301-002312	L2032	BEAD-SMD
3301-002312	L2033	BEAD-SMD
3301-002312	L2034	BEAD-SMD
3301-002312	L2037	BEAD-SMD
3301-002312	L7004	BEAD-SMD
3301-002312	L7009	BEAD-SMD
3301-002312	L7010	BEAD-SMD
3301-002331	L5001	BEAD-SMD
3301-002331	L6015	BEAD-SMD
3705-001708	RFS1000	CONNECTOR-COAXIAL
3709-001883	CN6001	CONNECTOR-CARD EDGE
3709-001892	CN6000	CONNECTOR-CARD EDGE
3711-007107	HEA7002	SOCKET-BOARD TO BOARD
3711-007173	HEA4002	HEADER-BOARD TO BOARD

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

3711-008508	HEA7001	HEADER-BOARD TO BOARD
3711-008800	HEA5020	HEADER-BOARD TO BOARD
3711-008800	HEA6201	HEADER-BOARD TO BOARD
3711-008824	HEA4001	HEADER-BOARD TO BOARD
3711-008824	HEA6010	HEADER-BOARD TO BOARD
3711-008847	HDC5000	CONNECTOR-BATTERY
3711-008995	HEA7000	HEADER-BOARD TO BOARD
3712-001604	ANT1002	CONNECTOR-TERMINAL
3712-001604	ANT1003	CONNECTOR-TERMINAL
3712-001604	ANT1004	CONNECTOR-TERMINAL
3712-001604	ANT1005	CONNECTOR-TERMINAL
3712-001604	ANT1009	CONNECTOR-TERMINAL
3712-001604	ANT2000	CONNECTOR-TERMINAL
3712-001604	ANT2001	CONNECTOR-TERMINAL
3712-001604	ANT2003	CONNECTOR-TERMINAL
3712-001604	ANT2004	CONNECTOR-TERMINAL
3712-001604	ANT2006	CONNECTOR-TERMINAL
3712-001604	ANT2007	CONNECTOR-TERMINAL
3712-001604	ANT2010	CONNECTOR-TERMINAL
3712-001604	ANT2013	CONNECTOR-TERMINAL
3712-001604	ANT4000	CONNECTOR-TERMINAL
3712-001604	ANT4001	CONNECTOR-TERMINAL
3712-001604	ANT4002	CONNECTOR-TERMINAL
3712-001604	ANT4010	CONNECTOR-TERMINAL
3712-001604	ANT5000	CONNECTOR-TERMINAL
3712-001604	ANT5001	CONNECTOR-TERMINAL
3712-001604	ANT5002	CONNECTOR-TERMINAL
3712-001604	ANT5004	CONNECTOR-TERMINAL
3712-001604	ANT6050	CONNECTOR-TERMINAL
3712-001604	ANT6051	CONNECTOR-TERMINAL
3712-001604	ANT6052	CONNECTOR-TERMINAL
3712-001604	ANT6053	CONNECTOR-TERMINAL
3712-001621	ANT2005	CONNECTOR-TERMINAL
3712-001633	ANT5003	CONNECTOR-TERMINAL
3712-001633	ANT5005	CONNECTOR-TERMINAL
3712-001694	ANT1001	CONNECTOR-TERMINAL
3712-001694	ANT2011	CONNECTOR-TERMINAL
3712-001731	ANT2020	CONNECTOR-TERMINAL
3722-004060	IFC6001	JACK-USB

5. MAIN Electrical Parts List

4709-002150	F4005	COUPLER-DIRECTION
4709-002284	F4001	FREQ-DISTRIBUTER
4709-002412	U1002	COUPLER-DIRECTION
4709-002452	F1000	FREQ-DISTRIBUTER
4709-002464	F1001	FREQ-DISTRIBUTER
4709-002484	U2006	FREQ-DISTRIBUTER
GH02-14019A	SC7100UP	ABSORBER-TAPE SHIELD CAN AP
GH62-00042A	CON7000	PAD GAP-SMD GASKET
GH63-09981A	CN7001	SHIELD-SUS PLATE
GH63-13700A	SC7100	SHIELD-CAN A
GH63-13701A	SC7104	SHIELD-CAN B
GH63-13701A	SC7105	SHIELD-CAN B
GH63-13703A	SC7103	SHIELD-CAN D
GH63-13704A	SC7102	SHIELD-CAN E
GH63-13705A	SC7101	SHIELD-CAN F
GH63-13706A	SC4000	SHIELD-CAN G
GH63-13752A	SC7000	SHIELD-CAN IFPMIC

Please consult the GSPN website (Samsung Portal) for the most recent version of the product's part list.