

Dimension Type Properties









setup in Revit

Graphics

Dimension String Type	Continuous 	Baseline 	Ordinate
Leader Type	Arc 	Line 	
Leader Tick Mark			
Show Leader When Text Moves	Beyond Witness Lines 	Away From Origin 	
Tick Mark			
Line Weight	Line wight: 1 	Line wight: 5 	
Tick Mark Line Weight	Line wight: 1 	Line wight: 5 	












visit **balkanarchitect.com** for beginner, intermediate and advanced **Revit** courses

Dimension Line Extension		
Flipped Dimension Line Extension	 <p>*Only works with arrow tick marks and dimensions that are really close together</p>	
Witness Line Control	Gap to Element	Fixed to Dimension Line
		
Witness Line Length	 <p>*Only works when "witness line control" is set to "fixed to dimension line"</p>	
Witness Line Gap to Element	 <p>*Only works when "witness line control" is set to "gap to element"</p>	
Witness Line Extension		
Witness Line Tick Mark	 <p>Witness line tick mark</p>	














*Witness Line Tick Mark is set to "Heavy End 3mm"

visit balkanarchitect.com for beginner, intermediate and advanced **Revit** courses

Centerline Symbol	 <p>Centerline symbol</p> <p>*Only works when dimensioning centerlines; Centerline symbol is set to "M_Centerline"</p>	
Centerline Pattern	 <p>*Only works when dimensioning centerlines; Centerline pattern is set to "Dot 1mm"</p>	
Centerline Tick Mark	 <p>*Only works when dimensioning centerlines; Centerline tick mark is set to "Open dot 3mm"</p>	
Interior Tick Mark Display	<p>Dynamic</p>  <p>Always Show</p>  <p>*Only use it when the "Tick Mark" is set to an arrow</p>	
Interior Tick Mark	 <p>*See the previous field to see when it applies</p>	
Color	<p>■ Black</p> 	<p>■ Red</p> 
Dimension Line Snap Distance	 <p>*This is only a snap parameter, it's not going to effect existing dimensions</p> <p>*Only works when "witness line control" is set to "fixed to dimension line"</p>	











visit balkanarchitect.com for beginner, intermediate and advanced **Revit** courses

Text

Width Factor	Set to 1 	Set to 1.8 70 76 84 120 90 	
Underline	OFF 	ON <u>70 76 84 120 90</u> 	
Italic	OFF 	ON <i>70 76 84 120 90</i> 	
Bold	OFF 	ON 70 76 84 120 90 	
Text Size			
Text Offset			
Read Convention	Up, then Left 	Up, then Right 	Horizontal 



visit **balkanarchitect.com** for beginner, intermediate and advanced **Revit** courses

Text Font	Ariel 		Impact 
Text Background	Opaque 		Transparent 
Alternate Units	None 	Right 	Below 
Alternate Units Prefix	 <p>*Only works when "Alternate Units" is set to "right" or "Below"; Alternate units prefix: alt:</p>		
Alternate Units Suffix	 <p>*Only works when "Alternate Units" is set to "right" or "Below"; Alternate units suffix: - alt</p>		
Show Opening Height			

visit **balkanarchitect.com** for beginner, intermediate and advanced **Revit courses**