

Introduction

In this chapter we will develop the mathematical model for the dynamic loudspeaker mechanical system. Our goal is to predict the time response of the system to an initial displacement or velocity. This reveals several key properties of the system including its natural resonant frequency and amplitude decay over time.

A real speaker is, of course, driven by some external power source to reproduce acoustic pressure. By considering the system apart from its driving conditions we can separate out the aspects which describe the mechanical system in all cases.

First we make the analogy between the dynamic loudspeaker and a mass on a spring. This is an apt comparison because the underlying mechanical elements are similar. Cone motion is subject to a restoring force from its compliant elements just as a spring provides such a force. Cone motion is also opposed by mechanical losses due to friction and drag. We find the same in the mass-spring system. The cone mass provides an inertia which must be overcome to produce motion just as in the mass-spring system.

Next we formalize the quantities and forces which describe the mass-spring system and develop the underlying differential equation that they imply. Constituent forces are added one at a time. The time response is analyzed at each step to show the effects of a progressively more complex analysis.

Last we show that an equivalent electrical system may be determined, which obeys the same differential equation. This motivates our future development of the analogous system circuit.

General equation

The most general form of the harmonic oscillator is given by the equation:

$$\Lambda_2 \ddot{y} + \Lambda_1 \dot{y} + \Lambda_0 y = \Gamma(t)$$

It is important to note that each derivative of the dependant variable is multiplied by a constant and that the source term $\Gamma(t)$ can be interpreted as an external force on the system. When $\Gamma(t) = 0$ the equation is termed 'homogenous.'

In mechanics this equation may represent the displacement of a mass whose motion is subject to a restoring force proportional to its displacement. The simplest of which is a mass on a spring.

The free oscillator

For such a system Hooke's Law gives:

$$F = -kx$$

where k is the so-called spring constant. Since, by Newton $F = ma$, this is

$$m\ddot{x} + kx = 0 \tag{1}$$

A solution to this equation is easy to determine by intuition. We require a solution x which is proportional to its second derivative. This limits our choices considerably. The sine and cosine functions come to mind.

We will proceed by formal application of differential equations theory to see if our intuition is supported.

$$x = Ae^{\alpha t} \tag{2}$$

and it's derivatives

$$\dot{x} = \alpha x \quad \ddot{x} = \alpha^2 x \tag{3}$$

plugging back into equation (1) and dividing through by mass

$$\alpha^2 mx + kx = 0$$

from which the α is determined to be

$$\alpha = \pm j\sqrt{\frac{k}{m}} = \pm j\omega_o$$

where we recognize that α must assume the units of frequency to keep our exponential argument unitless as required. Returnig to the solution (2)

$$x = A_1 e^{j\omega_o t} + A_2 e^{-j\omega_o t}$$

By application of Euler's identity this can be rewritten in terms of the sine and cosine functions as

$$x = A_1 [\cos(\omega_o t) + j\sin(\omega_o t)] + A_2 [\cos(\omega_o t) - j\sin(\omega_o t)]$$

Combining terms and renaming constants gives

$$x = B_1 \cos(\omega_o t) + B_2 \sin(\omega_o t)$$

Where B_1 and B_2 may be complex if necessary, and are determined by initial conditions.

It is apparent then that the system resonates at frequency ω_o with constant amplitude for all time. Though this fits intuition regards to its sinusoidal motion, we must admit that real mass-springs systems do not go on for eternity with the same amplitude. Our model must be refined to take mechanical damping into account.

The damped oscillator

We assume that, in addition to the restoring force, the system experiences a damping force proportional to its velocity $F_{damp} = -b\dot{x}$ yielding the system equation:

$$F = -kx - b\dot{x}$$

or

$$m\ddot{x} + b\dot{x} + kx = 0 \tag{4}$$

A suitable solution may be suggested either by intuition or by basic knowledge of differential equations. Since we might guess that the harmonic displacement should decay over time we might choose a solution like (2) and add an exponentially decaying term. This is indeed correct for a certain subclass of solutions. It would not, however, include systems with high mechanical damping, a door damper, for instance.

Instead we will take our cue from differential equations theory and try

$$x = Ae^{\alpha t} \tag{5}$$

and its derivatives

$$\dot{x} = \alpha x \quad \ddot{x} = \alpha^2 x$$

going back to the system equation (4)

$$m\alpha^2x + b\alpha x + kx = 0$$

dividing through by x and m gives the system characteristic equation

$$\alpha^2 + \frac{b}{m}\alpha + \frac{k}{m} = 0;$$

here we pause to take a result from above by noting $\frac{k}{m} = \omega_o^2$ and proceed with the quadratic equation to find the roots of α

$$\alpha = -\frac{b}{2m} \pm \sqrt{\left(\frac{b}{2m}\right)^2 - \omega_o^2} \quad (6)$$

we may save some space by assigning $\gamma = \frac{b}{2m}$ giving

$$\alpha = -\gamma \pm \sqrt{\gamma^2 - \omega_o^2}$$

now returning to the proposed solution (5) gives the linear combination

$$x = A_1 e^{t(-\gamma + \sqrt{\gamma^2 - \omega_o^2})} + A_2 e^{t(-\gamma - \sqrt{\gamma^2 - \omega_o^2})}$$

We must now understand this equation in physical terms. The interpretation of the solution x hinges upon the difference term beneath the square root. As we shall see three cases become aparent, these are

$$\begin{aligned} \gamma^2 - \omega_o^2 > 0 &\Rightarrow \text{Overdamped system} \\ \gamma^2 - \omega_o^2 < 0 &\Rightarrow \text{Underdamped system} \\ \gamma^2 - \omega_o^2 = 0 &\Rightarrow \text{Critically damped system} \end{aligned}$$

Overdamped

In the case of an overdamped system we can see that the radical expression must be positive. Further

$$-\gamma \pm \sqrt{\gamma^2 - \omega_o^2} < 0$$

from which we can see that both terms of our solution contain a decaying exponential term, the addition of which comprises the whole solution.

$$x = A_1 e^{-t(-\gamma + \sqrt{\gamma^2 - \omega_o^2})} + A_2 e^{-t(-\gamma - \sqrt{\gamma^2 - \omega_o^2})}$$

Qualitatively the response decays towards zero with increasing time. No oscillation occurs, hence the term 'overdamped.' Figure 1 shows a typical overdamped response.

Underdamped

In contrast the underdamped scenario takes a different form. Here the radical term must be negative. It is helpful to rewrite the roots of α in the following way

$$\alpha = -\gamma \pm i\sqrt{\omega_o^2 - \gamma^2}$$

The units of α must be that of angular frequency to keep the exponential argument in our solution unitless. From this we can also see that γ must, likewise, have units of angular frequency.

With this fact in hand we may interpret the radical term as a modification of the natural resonant frequency due to damping. The damped resonant frequency can then be expressed as

$$\omega_d = \sqrt{\omega_o^2 - \gamma^2}$$

Which leads to a more compact and intuitive form of the solution

$$x = A_1 e^{t(-\gamma + i\omega_d)} + A_2 e^{t(-\gamma - i\omega_d)}$$

and may be broken down further to

$$x = e^{-\gamma t} (A_1 e^{i\omega_d t} + A_2 e^{-i\omega_d t})$$

each term containing a decaying exponential and a complex exponential. To interpret the complex exponential terms we employ Euler's equation to find

$$x = e^{-\gamma t} (A_1 [\cos(\omega_d t) + i \sin(\omega_d t)] + A_2 [\cos(\omega_d t) - i \sin(\omega_d t)])$$

combining terms

$$x = e^{-\gamma t} ([A_1 + A_2] [\cos(\omega_d t)] + i[A_1 - A_2] [\sin(\omega_d t)])$$

The addition or subtraction of the arbitrary constants may be combined under new labels. Also the i factor may be absorbed into our chosen constants as no real-valued restriction has been placed upon them. This gives

$$x = e^{-\gamma t}(B_1 \cos(\omega_d t) + B_2 \sin(\omega_d t))$$

Finally sinusoidal terms of the same argument may be combined by a well known trigonometric identity resulting in

$$x = Be^{-\gamma t} \sin(\omega_d t + \phi)$$

As required the second order system has resulted in a solution with two unknowns, namely B and ϕ , which may be determined by initial conditions.

Importantly we note that our solution now has a clear physical interpretation. We expect oscillation with the damped frequency of ω_d which decays over time to zero owing to its leading exponential term.

Critically Damped

The last scenario to consider is when the radical expression is exactly zero. In real systems this is never strictly achievable but serves as a singular transition state between the over and underdamped scenarios. It is worth taking the time to describe its behavior.

Straight away we see that our expression for α in (6) produces only one root and hence our solution is no longer a linear combination with the required two constants. By basic differential equations theory or by direct computation we can see that another solution may be proposed, namely

$$x = tAe^{\alpha t}$$

leading to the entire solution

$$x = A_1 e^{\gamma t} + tA_2 e^{\gamma t}$$

where γ is as defined above. Qualitatively this solution is similar to the overdamped case. However it represents the fastest possible decay towards zero without oscillation. Any higher damping would lead to a slower approach, any lower damping would lead to undershooting zero and oscillatory behavior. Figure 1 shows one such critically damped response.




Figure 1: Under, Over, and Critically damped system response

General equation revisited

Having come this far we now look back on the results obtained in light of the general equation of harmonic motion.

In terms of constants given we can generalize the behavior of any system obeying this fundamental differential equation. Following the development above such a system has the characteristic equation

$$\alpha^2 \Lambda_2 + \alpha \Lambda_1 + \Lambda_0 = 0$$

whose roots are

$$\alpha = \frac{\Lambda_1}{2\Lambda_2} \pm \sqrt{\left(\frac{\Lambda_1}{2\Lambda_2}\right)^2 + \left(\frac{\Lambda_0}{\Lambda_2}\right)}$$

the solutions to the free, overdamped, underdamped, and critically damped scenarios are formally equivalent to those already given. In terms of our generalized constants the system exhibits the following characteristics

a natural resonant frequency of

$$\omega_o = \sqrt{\frac{\Lambda_0}{\Lambda_2}}$$

an exponential decay argument including

$$\gamma = \frac{\Lambda_1}{2\Lambda_2}$$

and a damped resonant frequency of

$$\omega_d = \sqrt{\omega_o^2 - \gamma^2}$$

Where damping is absent $\Lambda_1 = 0$ hence $\gamma = 0$ and no decay occurs. Where damping is present the value of $\gamma^2 - \omega_o^2$ determines the classification as underdamped, overdamped, or critically damped

Hence any system sharing the same governing differential equation may be immediately solved by considering only its constants.

The series L-C-R circuit




Figure 2: Sourceless series L-C-R circuit

From basic circuit theory we understand the current and voltage behavior of the usual passive elements to be:

Resistors, by ohms law

$$e = iR$$

Inductors

$$e = L \frac{di}{dt} \quad \text{and} \quad i = \frac{1}{L} \int e \, dt$$

Capacitors

$$e = \frac{1}{C} \int i \, dt \quad \text{and} \quad i = C \frac{de}{dt}$$

where e and i are voltage and current and L , C , and R denote inductance, capacitance, and resistance respectively.

From these a system equation for the series LCR circuit may be written. In particular we assign sum of the component voltage drops to be zero since there is no source, giving

$$L \frac{di}{dt} + iR + \frac{1}{C} \int i dt = 0$$

Taking the time derivative of both sides yields

$$L \frac{d^2 i}{dt^2} + R \frac{di}{dt} + \frac{1}{C} i = 0$$

We have arrived again at the familiar form of the harmonic oscillator. Drawing parallels to our mechanical analysis of the mass-spring system we can see:

$\Lambda_2 \Rightarrow \text{Mass} \Rightarrow \text{Inductance}$

$\Lambda_1 \Rightarrow \text{Damping Constant} \Rightarrow \text{Resistance}$

$\Lambda_0 \Rightarrow \text{Spring Constant} \Rightarrow 1/\text{Capacitance}$

The solutions of the LCR system current must, then, take identical forms to those of displacement in the mass-spring system. Further, and perhaps less obviously, the mass-spring system may be represented as a series LCR circuit if care is taken to map each parameter to its corresponding circuit element.

This translation into circuit form is known as lumped parameter modeling. It provides insight by availing us of the many tools and techniques used for circuit analysis.