

Command List

→ Ok Zira

- **Ok Zira**
 - Once you say “*ok Zira*”, you have 5 seconds to say any command.

→ Source Selection

- **Show PC**
 - **Show DVD**
 - **Show Laptop**
 - **Show DocCam**
- These will change the projector screen source to the corresponding spoken device.

→ Turning System on off

- | | |
|--------------------|--|
| • System On | - Turns the system on |
| • Shutdown | - Pops up a confirmation screen before shutting down |
| • Yes | - Shuts system down if the confirmation screen is open |
| • Cancel | - Cancels shutting down process |
| • No | - Also Cancels shutting down process (same as No) |

→ Volume Control

- | | |
|--------------------|--------------------|
| • Volume up | - Increases volume |
|--------------------|--------------------|

- **Volume Down** - Decreases Volume
- **Mute** - Mutes all Sounds
- **Unmute** - Unmutes all sounds

→ **Help**

- **Help** - Displays help page, this command can be said from any screen
- **Back** - Exits from help page display

→ **Conference Mode**

- **Start Conference** - Enters Conference Mode
- **Exit Conference** - Exits Conference Mode

→ **Camera Control**

- **Camera Control** - Displays Camera control page
- **Student Camera** - Selects student camera
- **Instructor Camera** - Selects instructor camera
- **Zoom In** - Zoom in whichever camera is selected
- **Zoom Out** - Zoom out whichever camera is selected
- **Pan Right** - Moves selected camera to the right
- **Pan Left** - Moves selected camera to the left
- **Pan Down** - Moves selected camera to the down
- **Pan UP** - Moves selected camera to the up

- Note: Any of these commands can be said and will work regardless of what the touch screen is showing, but if you want to see the touch panels being pressed you need to say camera control first, so the page with the camera control buttons can appear in the screen.

➔ Touch Panel Control

- **Wake**
 - Wakes up the touch panel screen when it is off
- **Sleep**
 - puts touch panel screen in standby mode