


## DN23E08 NANO 8ch analog relay expansion board manual



### Product Features:

1 Operating voltage: DC 12V/DC 24V

2 Operating Current : Standby current (Digital tube OFF) 12MA, Standby current 49MA (Digital tube ON), 1 relay open 75MA, 2 relays open 105MA, 3 relays open 131MA, 4 relays open 163MA, 5 relays open 184MA, 6 relays open 210MA, 7 relays open 256MA, 8 relays open 289MA

3 on-board resources: 1x RS485 Interface 8x opto-isolated inputs (low level trigger, NPN type), 4x 0/4-20MA Current Input, 4x 0-5V/10V Voltage Input, 4x buttons, 1x 4 bit digital tube display, 1x NANO V3.0 slots, 8x relay outputs

4 size 180\*72\*19mm(Only Board)

5 Weight : 184g(Only Board), 312g(with shell)

As long as you write ARDUINO code(sketch), You can use it to achieve a variety of delay timer function, such as:

RS485 Master-Slave Device(PLC MCU),

4x 0/4-20MA Current Collection,

4x 0-5V/10V Voltage Collection,

Motor forward and reverse,

Timing on,

Timing off,

Power-up delay,

Trigger delay,  
Infinite loop delay,  
A finite number of cyclic delays,  
Power sequencer,  
And so on.

This is an expansion board based on NANO V3.0, and the code(sketch) we provide is only used to test the experimental hardware.


If you need more functionality, write your own code. We do not provide additional code(sketch) and technical support

How to use: See video " DN23E08 DN24F08 Current\_Voltage\_RS485 Demo"

" DN23E08 DN24F08 Delay Relay Demo"


**Note: DN23E08 can not work independently, must be under the control of the NANO V3.0 board to work, If you do not have a NANO V3.0 board, purchase it separately or purchase a kit with NANO V3.0**

Application 1: Through the programming of NANO V3.0, various delay customization functions can be realized instead of PLC.



**Note: This is just an expansion board, you also need a NANO V3.0 for normal use.**

Application 2: It can be used as an RS485 master device instead of PLC/PC/touch screen to control various RS485 slave devices.



Note: This is just an expansion board, you also need a NANO V3.0 for normal use.