


Add a 100nF capacitor to every IC to please the gods of signal integrity.

Sheet: /	
File: board.sch	
<b>Title: BreadBinComputer</b>	
Size: A4	Date:
KiCad E.D.A. kicad (5.0.0)	Rev: Id: 1/3



Sheet: /BreadBinCPU/  
File: CPU.sch

# Title: CPU

Size: A4  
KiCad E.D.A. kicad (5.0.0)

Date:

Rev:  
Id: 2/3

