

LibreSolarBox assembly guide

DISCLAIMER

Please notice our following disclaimer. Due to the fact we are not providing a product in the legal sense, we are also not providing any warranty in any aspect.

The construction manual described here has been developed and tested by the team of cos(h) with care and to the best of our knowledge.

The team assumes no liability for the accuracy, completeness or quality of the information provided for the construction of the hardware described. Liability claims against the team for material, physical or immaterial damages caused by the use or non-use of the information provided or by the use of incorrect and/or incomplete information are excluded.

All information and instructions are non-binding. The team expressly reserves the right to change, supplement or delete parts of the pages or the entire offer without prior notice or to cease publication temporarily or permanently. By using the construction manual, the user accepts this disclaimer.

This document contains excerpts from the gos(h)-groups libresolarbox-projectpage at <https://github.com/CollectiveOpenSourceHardware/LibreSolarBox> .
Some of them were recorded during the Assembly Workshop at the Fablab St.Pauli, 08. July 2018

Environment and Tools

Preparation Steps

- Software tools
 - FreeCAD,
- Prepare tools and place
 - > foto of each part
 - table
 - crimping tool
 - screwdriver
 - side cutter
 - allen wrench

- Prepare material and components
 - Frame and Housing (in this case UniProKit)
 - screws, nuts
 - T-slot alu profile
 - 3D printed corner elements / connectors
 - bottom plate
 - housing plates
 - Battery pack
 - 3D printed battery case (bottom and cap -> download link to file)
 - battery cells
 - cell connectors
 - electrical components
 - Libre Solar components -> MPPT, *BMS*, (optional: CAN2Wifi)
 - (optional: RaspberryPi0)
 - wires - power wires (6 sq mm), balancing wires (2 sq mm)
 - ferrules, cable lugs
 - (optional: communication wire - ethernet cable)
 - plugs
 - *dc-output plugs (car plug, 2x)*
 - solar input plugs (Weidmüller PV Stick allows assembly w/o crimping and is compatible to MC4. Clips should be removed that the plug can be unmounted without tools)
 - *usb plugs*
 - *ON/OFF switch, pushbutton, integrated LED*
 - (optional: RJ45 jacks (2x))
 - (optional: epaper display+connection wire)

Assembly Steps Overview

1. Frame assembly

- 1.1 nuts into t-slot profile (
- 1.2 place profile in rectangle, place corner elements between profiles, screw together
- 1.3 repeat
- -> result: 2 connected rectangle frame
- 1.4 connect the 2 rectangle frames with profile
- -> result: boxframe

2. screw bottom plate on bottom side of boxframe

- -> result: boxframe with bottom plate

3. cut and crimping wires

- 3.1 ...

4. battery pack assembly -> !!!!!safety note!!!!

- 4.1 put battery cells in battery case (bottom part)
- 4.2 connect battery cells together
- 4.3 connect balancing wires with cells
- 4.4 connect power wires with battery cells
- 4.5 screw battery pack with bottom plate

5. mouting of electric components

Assembly

Assembly frame box

!!! For the framebox assembly we urgently recommend to use the detailed step-by-step-guide at https://github.com/case06/libresolarbox-v2_mobile/raw/main/doc/boxassemblyguide1d_osegci.pdf and see the framebox BOM at https://github.com/case06/libresolarbox-v2_mobile/raw/main/doc/bom_boxframe.pdf

Note: square nuts are not symmetric. When inserting them into T-Slot, keep the upper part outside. See picture [...] to determine the upper side of the nuts.
Create large square frames first.





- * Put larger profiles on the table and put plastic corners in the corners. Check orientation of the profiles. The holes on the side of the upper and the lower profile must be up.
- * Insert all necessary square nuts in the T-slots.
Hint: Use a bolt to push a square nut into a slot.
- * Control the placement of corners, screws and square nuts.
Start with the bottom part.
- * Connect a corner to the bottom.
- * Connect a side part to the bottom.
- * Connect another corner to the bottom.
- * Connect another side to the bottom.
- * Connect remaining corners and the upper part.
- * Connect small T-profiles to a big square frame. The holes on the side of the large frame must be later outside of the box.
- * Insert nuts into short profiles. Two nuts into the short profiles on the top of the future box. Four nuts into every short profile on the bottom of the future box.
- * Add the bottom blending.



Add batteries

- * Mark the batteries with numbers *1*, *2*, *3*, and *4*.
 - * Put batteries into the battery case.
 - * Isolate main **+** and main **-** of the batteries. (Is it important to have main "+" or "-" on particular side of the battery block?)
- Now carefully connect batteries one by one, from *4* to *1*.
- * Put connector between *4* and *3*.
 - * Put a washer on the connector on the side *4*.
 - * Put thin cable with tag *4* on the washer
 - * Put another washer on the connector of the thin cable. (Too many washers, check it again).
 - * Put a bolt throw connector, washers and thin cable and tighten it. (bots or screws?).
 - * Put a washer on connector on side *3*.
 - * Put a bolt throw the washer and the connector and tighten it.
 - * Connect in the simmilar way batteries *3* with *2* and *2* with *1*.
 - * Do **not** remove isolation from main **+** and main **-** yet.



Sheet1



Page 6

Connect BMS

- * Solder cables to the on/off-switch.
- * Mount blue thick cables and USB+ to *PWR-* of BMS.
- * Mount red thick cables and USB- to *PWR+* of BMS.
- * Connect two blue cables (- or +?) to two DC out sockets.
- * Connect two red cables to two DC out sockets.
- * Connect two thin cables from on/off-switch to BMS.



Connect to MPPT




- * Connect all cable ends without blade connectors to MPPT.
- * Check that these cable are well mounted.



Assembly interface blending

The interface blending is the blending with sockets.



- * Put sockets with cables into the blending
- * Mount the interface blending to the frame



Connect battery block

(In this part BAT- and BAT+ seems to be confused. I need resolve it.)

- * Remove isolation from **main -**.
 - * Connect two cables to **main -**.
 - * Connect thick blue cable to *BAT-* on BMS.
 - * Connect two cables to **main -**
 - * Connect balancing to *BAT-* on BMS. (Is this correct?)
- (Must the on/off switch must be off before add the fuse? How one can see it?)
- * Add fuse.
 - * Check the voltage (where?): It must be around 12.8 V.
 - * Switch off the on/off switch.
 - * Check the voltages. It must be falling until 0. The voltage does not drop imidiately to 0, because there is remaining electric charge in the capacitors.
 - * Switch on.
 - * Check Voltage between *POW+* and *POW-*. It must be about 12.8V.
 - * Remove the fuse. (I missted this step in my notes. Is it correct here?).



Connect Raspberry


- * Connect an internet cable to Raspberry
- * Connect the internet cable to BMS.
- * Connect an internet cable to CAN socket on the blending.
- * Connect the other end of the cable to BMS.
- * Mount the Raspberry with two-side tape to the box.



Add back blending


(Better do it before interface blending because the interface blending is not flat.)

- * Put SolarBox on the interface.
- * Position square nuts. They must have the same position as the holes of the blending.
- * Put blending on the frame.
- * Insert bolts through the blending into the square nuts. Tighten the bolts.



Mount side blending

- * Put the SolarBox on the side.
- * Position the square nuts.
- * Put the blending on the frame.
- * Insert bolts through the blending into the square nuts. Tighten the bolts.



Mount to blending with handles.

- * Put the SolarBox on the bottom.
- * Position square nuts for the top blending.
- * Put top blending.
- * Put handles on the top blending.
- * Insert **longer** bolts through the handles, the blending and square nuts. Use normal bolts for other parts of the blending.
- * Tighten the blending.



Mount last side blending

- * Check once more if all the connection are good.
- * Insert the fuse.
- * Put the SolarBox on the side.
- * Position the square nuts.
- * Add the blending.
- * Tighten the bolts.

