

NAVIGATION

Move Cursor - UP or DOWN or LEFT or RIGHT

Screen Navigation - hold SHIFT + [UP or DOWN or LEFT or RIGHT]

EDITING

Change Value fine - hold EDIT + [LEFT or RIGHT]

Change Value coarse - hold EDIT + [UP or DOWN]

Cut Value or set to default - EDIT + OPTION

PLAY

Play All Tracks from song cursor - hold SHIFT + PLAY

Mute Current Track - hold OPTION + SHIFT
(latch mute by releasing OPTION first)

Solo Current Track - hold OPTION + PLAY
(latch solo by releasing OPTION first)

Clear All Mute and solos - hold OPTION + hold SHIFT + PLAY

SELECTION

Enter Selection Mode - hold SHIFT + OPTION
(tap OPTION to cycle through modes)

Copy Selection (exit mode) - OPTION

Paste Copy Buffer - hold SHIFT + EDIT

FILE BROWSER

Preview Sample - PLAY

Sort Directory - SHIFT + OPTION

Delete Selected File - EDIT + OPTION

LEGEND

EDIT - Select / Enter

OPTION - Cancel / Back

SHIFT - Shift / Alt

PLAY - Start / Stop

Selection Mode Only - Highlighted commands

MIXER SCREEN

Create Snapshot - hold SHIFT + OPTION

Recall Snapshot - hold SHIFT + EDIT

SONG SCREEN

Cue Row while playing - hold LEFT + PLAY

Create new chain - double-tap EDIT

Clone and Paste chain alone - hold SHIFT + OPTION then EDIT

Deep Clone chain & phrases - hold SHIFT + OPTION then double-tap EDIT

Solo Tracks left or right - hold OPTION + [LEFT or RIGHT]

Solo Row Live Mode - hold OPTION + PLAY

Toggle Live Mode - hold SHIFT + LEFT

Jump 16 Rows up or down - hold OPTION + [UP or DOWN]

Move Selection - hold EDIT + [UP or DOWN]

Render Selection - double-tap EDIT

Bookmark Mark a Chain - Triple-tap OPTION

Track Select / Reorder Move Track - Row 00: 2xUP. Move: Hold EDIT + L/R

CHAIN SCREEN

Create new phrase - double-tap EDIT

Clone and Paste phrase - hold SHIFT + OPTION then EDIT

Deep Clone phrase & notes - hold SHIFT + OPTION then double-tap EDIT

Jump to Track left or right - hold OPTION + [LEFT or RIGHT]

Jump to Chain previous or next - hold OPTION + [UP or DOWN]

Play All Tracks continue song from cursor position - hold SHIFT + PLAY

SAMPLE EDITOR

Lazy Chop add slice marker - during playback, hold PLAY then tap EDIT

Zoom / Fine Select - hold EDIT + [LEFT or RIGHT]

Snap Selection to beat - hold OPTION + [UP or DOWN]

INSTRUMENT SCREEN

Preview Instrument - hold EDIT + PLAY

Copy Instrument - hold SHIFT + OPTION

Jump to Instrument previous or next - OPTION + [LEFT or RIGHT]

Quick FX Jump auto-assign FX - on parameter, hold SHIFT + [LEFT or RIGHT]

Edit Parameter - EDIT + [Touchscreen LEFT and RIGHT]

Map Parameter - OPTION + [Touchscreen LEFT and RIGHT or UP and DOWN]

PHRASE SCREEN

Create new instrument - on instrument column, EDIT (double-tap)

Clone and Paste instrument - hold SHIFT + OPTION then EDIT

Jump to Track left or right - hold OPTION + [LEFT or RIGHT]

Jump to Phrase previous or next - hold OPTION + [UP or DOWN]

Transpose Octave - hold SHIFT + [UP or DOWN]

Transpose Semitone - hold SHIFT + [LEFT or RIGHT]

Interpolate - (single column) hold SHIFT + EDIT

Move selection - (multi column) hold EDIT + [UP or DOWN]

Note Fill - (note column) hold OPTION + LEFT

Random Fill - (note column) hold OPTION + RIGHT
velocity can be randomized if selected

Randomize Notes Up or Down - (note column) hold OPTION + [UP or DOWN]

Cycle Commands - on command column, hold OPTION + [UP or DOWN]

Effect Help on command column - hold EDIT + [UP or DOWN]

INSTRUMENT POOL

Select / Load - EDIT

Preview Instrument - PLAY

Move Instrument reorder list - on name column, hold EDIT + [UP or DOWN]

Delete Instrument - on name column, EDIT + OPTION

Clone Instrument - on name column, hold SHIFT + OPTION