



Device TG LITE PLUS



TG LITE PLUS

TG LITE PLUS:

TG Lite plus is designed for customers that simply need 24X7 location information (Tracking) of their fleet or vehicle.

It has internal GPS & GSM antenna, For location tracking of devices.

Provides you the battery backup.

By using this you can find out the current location of your vehicle.

If you have multiple device installed then you can see all the vehicle related information on the map.

Has capability of remotely stopping the vehicle with a simple SMS command or by pressing a button from the Tracking Genie mobile app.

Tracking and Remote Immobilization that keeps the track of various features of vehicles like ignition, air condition etc.



Contd... TG LITE PLUS

Hardware Specification

- Internal GPS & GSM antenna
- Battery Backup
- Current Location
- 3 Digital Input
- Inbuilt Memory
- SOS Alert
- Overspeed Alert

Software Specification

- 30 days historic data
- Multi-Vehicle view on map
- Live Tracking
- Remote Shutdown
- Ignition ON/OFF Alerts
- GEO Fence Alert



Features of TG LITE PLUS

These are some features of TG LITE PLUS device:

Internal GPS & GSM antenna.

Provides you the historic data of last 30 days.

It provides you the information regarding the current location of the Vehicle.

Replay tracking is used to see the tracking of the device for last 30 days. It'll facilitate you to see the tracking like video. You can pause it and fast forward it also.

Account related with this device provides you the facility to create sub users also. Sub users are helpful when you need to track information of several vehicles.

User Log is useful to track a sub user is working or not.

This device provides you the facility of live tracking, Means You can track every movement of



Contd... Features of TG LITE PLUS

Features (Contd...)

If battery gets disconnected then a alert will come through SMS/ Email.

If the vehicle doesn't move or no data is transmitted for 24 hours then a alert will come through SMS/ Email.

You can make GEO FENCE areas, Means a client can identify that it's vehicle can remain inside that region.

A alert will come through SMS/ Email, If your vehicle goes outside the GEO FENCE or Come inside the GEO FENCE area.

You can enter Min. KM, Min. time duration or both. You'll get a alert if device crosses the limit. It's helpful in Vehicle Maintainance.

It provide you the graphicle fleet of your vehicles or the vehicle status.



Contd... Features of TG LITE PLUS

Features (Contd...)

You can shutdown the device remotely.

If SOS button pressed then you'll get a alert through SMS/Email.

You'll get a alert through SMS/Email. For over speed of vehicle.

You'll get a alert through SMS/Email. For Ignition ON/OFF.



Reports Generated In TG LITE PLUS

Following Reports can be generated using the TG LITE, Report can be generated for a specified range of date:

Vehicle status report.

Raw data(Activity Record): This include all the information which a device can provide like Overspeed, GEO FENCE etc. The data will be updated in 30 seconds.

Overspeed report when your vehicle crossed the Speed limit.

Historical report of the vehicle for last 30 days.

Log Report: It'll give you the details related to the sub-user. A report can be generated of his working.

It'll generate the report for the low battery.



Reports Generated In TG LITE PLUS

Reports (Continue...):

It'll generate the history report station wise.

Every Client gets limited SMS, This device will generate the full report where the SMS's are utilized.

It'll generate the report that how many times a vehicle was halted.

Client can set the max speed in the device, If a vehicle cross that speed report can be generated for the overspeed.

SOS alarm report can be generated.

Report for the digital input can be generated.

Report of the Device battery drain can be generated.



Thank You
