

Game buttons are all 6x6 tap-tic buttons. The up/down/left/right buttons can be replaced by a 5-direction mini joystick-like integrated button. Use small PC speakers or buzzers without an internal beeper circuit as sound output, Test out the circuit on a breadboard first before soldering on a circuit board. Use laminated (isolated) wire for connection between points. Use the small soldering tip and apply flux. Based on original version of Attiny Joypad created by Daniel C. (Electro L.I.B) 2018 GPL V3

TITLE: gametiny		REV: 1.0
Date: 2018-11-18		Sheet: 1/1
EasyEDA V5.8.20	Drawn By: Billy Cheung	