



Mistake in brd-file:
connect ground plane
to GND by HAND !