


YOUR CURRENT VEHICLE

2018 Chrysler Pacifica

Removal & Installation


REMOVAL AND INSTALLATION

REMOVAL




2310000957

1. Position the door glass in the up position.
2. Remove the door trim panel ([Refer to Body/Door - Front/PANEL, Door Trim/Removal and Installation](#)).
3. Disconnect the wire harness connectors (1).
4. Open the access cover (2).
5. Unseat the rubber grommet (3) and insert through the carrier plate.



2310000955


6. Disconnect the wiring harness routing clips.
7. Remove the two lower outside rearview mirror nuts (1).
8. Position the door glass in the fully lowered position.
9. Remove the one upper outside rearview mirror nut (1).




2310080954

10. Remove the outside rearview mirror (1).
11. Route the wiring harness (3) through the door opening (2).
12. Remove white plastic assembly aid from the top forward hole in the door opening.

INSTALLATION



1. Route the wiring harness (3) into the door opening (2).
2. Position the outside rearview mirror (1) onto the vehicle.




3. Install the one upper outside rearview mirror nut (1) and tighten to the proper [Torque Specifications](#).
4. Raise the door glass to fully up position.
5. Install the two lower outside rearview mirror nuts (1) and tighten to the proper [Torque Specifications](#).

NOTE

To prevent contact with the door glass, be certain to route the wiring harness forward of the front window channel.

6. Secure the wiring harness routing clips.



2310000957

NOTE

The rubber grommet must face rearward on the door to prevent interference with the door trim panel installation.

7. Insert the rubber grommet (3) through the carrier plate and seat fully.
8. Close the access cover (2).
9. Connect the wire harness connectors (1).
10. Install the door trim panel ([Refer to 23 - Body/Door - Front/PANEL, Door Trim/Removal and Installation](#)).