

YOUR CURRENT VEHICLE

2018 Chrysler Pacifica

Removal & Installation

REMOVAL AND INSTALLATION

REMOVAL

1. Disconnect and isolate the battery negative cable.




2. Release retainer (1) securing the sliding door wiring harness to the track.



3. Disconnect the module and drive unit connector from the sliding door wiring harness (1).


4. Remove the sliding door trim panel.




5. Disconnect the sliding door wire harness from body wiring harness connector (1).

6. Using door trim panel tool

Remover, Trim



or equivalent, remove the wire harness routing clips located.



7. Remove the harness tie down retaining screws (1) at the bottom of the sliding door.

8. Pull the harness assembly out (2) and remove from vehicle.

INSTALLATION

1. Position the wire harness into the sliding door track cavity and route the harness properly to the sliding door.
2. Secure the harness to the door using the tie down retainers.
3. Connect the sliding door wire harness to the body wiring harness connector in the sliding door.
4. Install the retainers at the bottom of the sliding door that hold the harness to its proper routing position.
5. Connect the wiring harness plastic retainer to the track.
6. Connect the sliding door wire harness connector to the connector located in the trough.
7. Connect the battery negative cable.