


YOUR CURRENT VEHICLE

2018 Chrysler Pacifica

Removal & Installation


REMOVAL AND INSTALLATION

REMOVAL

**2309081030**

1. Remove the lower liftgate trim panel ([Refer to 23 - Body/Decklid/Hatch/Liftgate/Tailgate/PANEL, Trim, Liftgate/Removal and Installation](#)).
2. Disconnect the wire harness connector from the lamp bar (1).
3. Remove the six plastic nuts.
4. Using a suitable sized socket, install the socket over the squeeze fasteners to release the tabs and remove the lamp bar.

INSTALLATION



2309081030

1. Position the lamp bar (1) onto the liftgate and install the nuts. Tighten the nuts securely.
2. Connect the wire harness connector.
3. Install the lower liftgate trim panel ([Refer to 23 - Body/Decklid/Hatch/Liftgate/Tailgate/PANEL, Trim, Liftgate/Removal and Installation](#)).