


YOUR CURRENT VEHICLE

2018 Chrysler Pacifica

Removal & Installation


REMOVAL AND INSTALLATION

REMOVAL




1305080024

1. Remove the front belly pan ([Refer to Frame and Bumpers/Under Body Protection/BELLY PAN/Removal and Installation](#)).(Refer To List 1)
2. Remove the screws (1) attaching the wheelhouse splash shields to the engine belly pan.




3. Remove the two front push pin fasteners (1).
4. Remove the push pin fastener (3).
5. Remove the eight screws (4) and remove the engine belly pan (2).

INSTALLATION



1. Install the engine belly pan (2) and
2. Install the push pin fastener (3).
3. Install the two front push pin fasteners (1)
4. Install the eight screws (4) tighten the fasteners to the proper [\(Torque Specifications\)](#).



1305080024

5. Install the screws (1) attaching the wheelhouse splash shields to the engine belly pan.
6. Install the front belly pan ([Refer to 13 - Frame and Bumpers/Under Body Protection/BELLY PAN/Removal and Installation](#)).(Refer To List 1)

Refer To List:

List 1

- [13 - Frame and Bumpers / Under Body Protection / BELLY PAN, Engine / Removal and Installation](#)
- [13 - Frame and Bumpers / Under Body Protection / BELLY PAN, Front / Removal and Installation](#)
- [13 - Frame and Bumpers / Under Body Protection / BELLY PAN, Rear / Removal and Installation](#)
- [13 - Frame and Bumpers / Under Body Protection / BELLY PAN, Rear Suspension / Removal and Installation](#)
- [13 - Frame and Bumpers / Under Body Protection / BELLY PAN, Side / Removal and Installation](#)