


YOUR CURRENT VEHICLE

**2018 Chrysler Pacifica**

## Removal & Installation

### REMOVAL AND INSTALLATION

#### REMOVAL




2309097065

1. Remove the liftgate trim panels ([Refer to Body/Decklid/Hatch/Liftgate/Tailgate/PANEL, Trim, Liftgate/Removal and Installation](#)).
2. Unclip the rear washer hose (2) and disconnect it at the fitting (3).
3. Disconnect the wire harness connector (1).
4. Remove the covers (8) on both sides of the liftgate and the nuts behind them.
5. Remove the three nuts (7).
6. Remove the push fasteners and the pinch sensors (5) on both sides of the liftgate.
7. Remove the screw (6) on both sides of the liftgate.
8. Using pliers, release the two pinch fasteners (4) and remove the spoiler.

## INSTALLATION

### NOTE

When the spoiler is removed for repair or replacement, the gaskets at the spoiler attachment locations should be replaced.



2309097065

1. Position the spoiler onto the liftgate and engage the pinch fasteners.
2. Install the five nuts and tighten securely, starting from the center of the spoiler.
3. Install the nut covers (8) on both sides of the liftgate.
4. Install the screw (6) on both sides of the liftgate.
5. Install the pinch sensors (5) on both sides of the liftgate.
6. Connect the wire harness connector (1).
7. Connect the rear washer hose (3) and clip it onto place (2).
8. Install the liftgate trim panels ([Refer to Body/Decklid/Hatch/Liftgate/Tailgate/PANEL, Trim, Liftgate/Removal and Installation](#)).