


YOUR CURRENT VEHICLE

2018 Chrysler Pacifica

Removal & Installation


REMOVAL AND INSTALLATION

REMOVAL



1. Disconnect and isolate the negative battery cable.
2. Open the rear observation mirror (3).
3. Remove the two screws (2).
4. Pull down at the front of the overhead console (4) to lower, then push forward to release the hooks (1) and remove.
5. Lower slightly and disconnect the wire harness connector.

INSTALLATION



1. Connect the wire harness connector to the overhead console (4).
2. Position the hooks (1) into the roof, then push up to engage the front retaining clips.
3. Open the rear observation mirror (3) and install the screws (2). Tighten the screws securely.
4. Connect the negative battery cable.