


YOUR CURRENT VEHICLE

2018 Chrysler Pacifica

Removal & Installation


REMOVAL AND INSTALLATION

REMOVAL




130307B951

1. Disconnect and isolate the negative battery cable.
2. Raise and support the vehicle ([Refer to Vehicle Quick Reference/Hoisting/Standard Procedure](#)).
3. Remove the rear belly pan ([Refer to Frame and Bumpers/Under Body Protection/BELLY PAN/Removal and Installation](#)).(Refer To List 1)
4. Remove the four screws (1) and separate the rear wheelhouse splash shield (2) from the rear fascia.




2313084279

5. Remove the side support bolts (2) and using trim stick
Trim Stick




or equivalent (1), release the rear of the fascia support clip.




1303084279

6. Remove the nut (1) and disconnect the wire harness ground terminal.




1303078901

7. Remove the rear tail lamp assemblies ([Refer to 08 - Electrical/Lamps/Lighting - Exterior/LAMP, Tail/Removal and Installation](#)).
8. Remove the upper (1) and lower (2) screws and separate the upper fascia attachment clips.




1303079802

9. Separate the fascia clips (2) from the quarter panel support brackets (1) and remove the fascia assembly (3).




1309096125

10. Disconnect all wire harness connectors (1) as necessary.




1303096067

11. Disconnect the remaining wire harness connectors (1) and remove the wire harness (2).


**2313094380**

12. Release the clips and remove the energy absorber (2) from the fascia (1).


INSTALLATION

**2313094380**


1. Position the energy absorber (2) back onto the fascia (1) and seat fully.




2. Install the wire harness (2) and connect all the wire harness connectors (1).




3. Position the fascia back and connect any wire harness connectors (1) as necessary.




4. Install the fascia (3) onto the vehicle and seat the attachment clips (2) onto the support brackets (1) fully.



5. Seat the upper clips fully and install the upper (1) and lower screws (2).
6. Install the rear tail lamp assemblies ([Refer to 08 - Electrical/Lamps/Lighting - Exterior/LAMP, Tail/Removal and Installation](#)).



7. Install the wire harness ground terminal and install the nut (1).



8. Position the rear wheelhouse splash shield (2) back and install the four screws (1).

9. Install the rear belly pan ([Refer to 13 - Frame and Bumpers/Under Body Protection/BELLY PAN/Removal and Installation](#)).(Refer To List 1)

10. Connect the negative battery cable.

Refer To List:

List 1

- [13 - Frame and Bumpers / Under Body Protection / BELLY PAN, Engine / Removal and Installation](#)

- [13 - Frame and Bumpers / Under Body Protection / BELLY PAN, Front / Removal and Installation](#)
- [13 - Frame and Bumpers / Under Body Protection / BELLY PAN, Rear / Removal and Installation](#)
- [13 - Frame and Bumpers / Under Body Protection / BELLY PAN, Rear Suspension / Removal and Installation](#)
- [13 - Frame and Bumpers / Under Body Protection / BELLY PAN, Side / Removal and Installation](#)