


YOUR CURRENT VEHICLE

2018 Chrysler Pacifica

Removal & Installation


REMOVAL AND INSTALLATION

REMOVAL




2312082042

1. Remove the front carrier plate ([Refer to Body/Doors - Sliding/PLATE, Carrier/Removal and Installation](#)).
([Refer To List 1](#))
2. Release the retaining clips (1) and separate the exterior handle support bracket (2) from the presenter bracket.



2312002048


3. Disconnect the cable (1) from the bracket (2) and remove the cable from the carrier plate.



2312002009


4. Disconnect the cable (2) from the hold open latch (1) and remove the cable assembly.

INSTALLATION




2312002009

1. Install the cable assembly and connect the lower part (2) to the hold open latch (1).



2312002040

2. Install the control cable to the front carrier plate.
3. Connect the control cable (1) to the exterior handle bracket (2).



2312082042

4. Install the exterior handle support bracket (2) onto the presenter bracket and seat the clips (1) fully.
5. Install the front carrier plate ([Refer to 23 - Body/Doors - Sliding/PLATE, Carrier/Removal and Installation](#)).(Refer To List 1)

Refer To List:

List 1

- [23 - Body / Doors - Sliding / PLATE, Carrier Front / Removal and Installation](#)
- [23 - Body / Doors - Sliding / PLATE, Carrier Rear / Removal and Installation](#)