


YOUR CURRENT VEHICLE

2018 Chrysler Pacifica

Removal & Installation


REMOVAL AND INSTALLATION

REMOVAL



1305080012


1. Remove the rear suspension belly pan ([Refer to 13 - Frame and Bumpers/Under Body Protection/BELLY PAN/Removal and Installation](#)).(Refer To List 1)
2. Remove the screws (1) securing the rear belly pan to the rear wheelhouse splash shield.



1304058523

3. Twist and release the two decking aids (2).
4. Remove the seven nuts (3) and remove the four rear screws (4).
5. Remove the two side screws (1).
6. Remove the rear belly pan.


INSTALLATION



1304058523

1. Install the rear belly pan up into the rear fascia.
2. Seat the two decking aids (2) fully.
3. Install the seven nuts (3) and the four rear screws (4).

4. Install the two side screws (1) and tighten all fasteners to the proper [\(Torque Specifications\)](#).



1305080012

5. Install the screws (1) securing the rear belly pan to the rear wheelhouse splash shield.
6. Install the rear suspension belly pan [\(Refer to 13 - Frame and Bumpers/Under Body Protection/BELLY PAN/Removal and Installation\)](#).(Refer To List 1)

Refer To List:

List 1

- [13 - Frame and Bumpers / Under Body Protection / BELLY PAN, Engine / Removal and Installation](#)
- [13 - Frame and Bumpers / Under Body Protection / BELLY PAN, Front / Removal and Installation](#)
- [13 - Frame and Bumpers / Under Body Protection / BELLY PAN, Rear / Removal and Installation](#)
- [13 - Frame and Bumpers / Under Body Protection / BELLY PAN, Rear Suspension / Removal and Installation](#)
- [13 - Frame and Bumpers / Under Body Protection / BELLY PAN, Side / Removal and Installation](#)