


YOUR CURRENT VEHICLE

2018 Chrysler Pacifica

Removal & Installation


REMOVAL AND INSTALLATION

REMOVAL



2321104739


1. Open the sunshade fully.
2. Move the front glass to the vent position.
3. Disconnect and isolate the negative battery cable.
4. Separate the mechanism covers (1) from the front glass.



2321104740

5. Remove the six screws (1) then remove the front glass.

INSTALLATION



2321104740

1. Position the front glass and loosely install the six screws (1).
2. Connect the negative battery cable and verify that the sunroof is in the fully closed position.
3. Adjust the front glass ([Refer to Body/Sunroof/GLASS, Sunroof - Adjustments](#))(Refer To List 1).
4. Secure the mechanism covers onto the front glass.
5. Verify the sunroof operation.

Refer To List:

List 1

- [23 - Body / Sunroof, Dual Pane / GLASS, Sunroof, Front / Adjustments](#)
- [23 - Body / Sunroof, Dual Pane / GLASS, Sunroof, Rear / Adjustments](#)