


YOUR CURRENT VEHICLE

2018 Chrysler Pacifica


Removal & Installation

REMOVAL AND INSTALLATION

REMOVAL




1. Remove the rear fascia ([Refer to Frame and Bumpers/Bumpers/FASCIA, Rear/Removal and Installation](#)).
2. Remove the side bolts (1) and the bottom bolts (2).



1303079099


3. Remove the hitch assembly (2) from the frame rails (1).

INSTALLATION



1303079099

1. Install the hitch assembly (2) onto the frame rails (1).



2. Install the lower bolts (2) and the side bolts (1).
3. Tighten the side bolts (1) to the proper [\(Torque Specifications\)](#).
4. Tighten the lower bolts (2) to the proper [\(Torque Specifications\)](#).
5. Install the rear fascia [\(Refer to Frame and Bumpers/Bumpers/FASCIA, Rear/Removal and Installation\)](#).