

YOUR CURRENT VEHICLE

**2018 Chrysler Pacifica**

## Removal & Installation

### REMOVAL AND INSTALLATION

#### REMOVAL




2313083327

#### WARNING


Always wear eye and hand protection when servicing the mirror assembly. Failure to observe these warnings may result in personal injury from broken glass.

1. Disconnect and isolate the negative battery cable. If equipped with an Intelligent Battery Sensor (IBS), disconnect the IBS connector first before disconnecting the negative battery cable.
2. Place thumbs behind mirror glass case (1) and push out from the mirror assembly. This will disengage the mirror glass case's snap attachment feature.




3. If so equipped, disconnect the wire harness connectors (1 and 3) and remove the glass (2).

## INSTALLATION



1. If so equipped, connect the wire harness connectors (1 and 3) to the mirror glass.

2. Route the wiring to the glass.



3. Position the mirror glass (2) and align the retainers with the inner circular support (1).
4. Push the mirror glass into (2) the inner circular support (1) and seat the mirror glass fully. An audible click will be heard.
5. Connect the negative battery cable. If equipped with an Intelligent Battery Sensor (IBS), connect the IBS connector to the negative battery cable.