


YOUR CURRENT VEHICLE

2018 Chrysler Pacifica

Removal & Installation

REMOVAL AND INSTALLATION

REMOVAL



1. Using a small pry tool, open the screw cover (3) and remove the screw (2).
2. Rotate the visor upward towards the roof to remove it from the opening.
3. If equipped, disconnect the harness connector.

INSTALLATION



NOTE

If installing a NEW service part, the new visor will come with a clip and screw. It is not necessary to use the new clip if the existing clip has not been damaged during removal.

1. If equipped, connect the harness connector.
2. Install the sun visor (1) into the headliner opening and install the screw (2). Tighten the screw securely.
3. Close the screw cover (3).