


YOUR CURRENT VEHICLE

2018 Chrysler Pacifica

Removal & Installation


REMOVAL AND INSTALLATION

REMOVAL



1. Remove the side belly pan ([Refer to Frame and Bumpers/Under Body Protection/BELLY PAN/Removal and Installation](#)).(Refer To List 1)
2. Remove the two rear screws (3).
3. Remove the three nuts (1).
4. Remove the two push-pin fasteners (2) and remove the belly pan.

INSTALLATION



1. Install the rear suspension belly pan and install the two push pin fasteners (2).
2. Install the two rear screws (3).
3. Install the three nuts (1) and tighten all the fasteners to the proper [\(Torque Specifications\)](#).
4. Install the side belly pan ([Refer to 13 - Frame and Bumpers/Under Body Protection/BELLY PAN/Removal and Installation](#)).(Refer To List 1)

Refer To List:

List 1

- [13 - Frame and Bumpers / Under Body Protection / BELLY PAN, Engine / Removal and Installation](#)
- [13 - Frame and Bumpers / Under Body Protection / BELLY PAN, Front / Removal and Installation](#)
- [13 - Frame and Bumpers / Under Body Protection / BELLY PAN, Rear / Removal and Installation](#)
- [13 - Frame and Bumpers / Under Body Protection / BELLY PAN, Rear Suspension / Removal and Installation](#)
- [13 - Frame and Bumpers / Under Body Protection / BELLY PAN, Side / Removal and Installation](#)