


YOUR CURRENT VEHICLE

**2018 Chrysler Pacifica**

## Removal & Installation


### REMOVAL AND INSTALLATION

#### REMOVAL



1. Using a trim stick or equivalent, remove the cover (1).
2. Remove the two bolts (3).
3. By hand, pull at the top of the A-pillar trim panel (2) working towards the bottom releasing the retaining clips.
4. Lift the A-pillar trim panel upward and remove it from the instrument panel.

#### INSTALLATION



1. Position the A-pillar trim panel (2) down into the top of the instrument panel.
2. Starting at the bottom of the A-pillar trim panel, align the retaining clips and hand tap to engage.
3. Install the bolts (3) and tighten securely.
4. Install the cover (1).