


YOUR CURRENT VEHICLE

2018 Chrysler Pacifica


Removal And Installation

REMOVAL AND INSTALLATION

REMOVAL


**2312064823**

1. Open the sliding door and remove the rear belt molding screw (1).




2. Remove the belt molding (1) from the glass opening flange (2).

INSTALLATION



1. Position the molding (1) onto the glass opening flange (2) and seat fully.

**2312064023**

2. Install the rear belt molding screw (1).