

YOUR CURRENT VEHICLE

2018 Chrysler Pacifica


Removal & Installation

REMOVAL AND INSTALLATION

REMOVAL




1. Move the front glass into the full open position.
2. Push down the lower rod (1) to remove from the under plastic clips (2).



3. Rotate the wind deflector (1) up and remove the spring arms (2) from the slots in the frame.

INSTALLATION



1. Position the deflector spring arms (2) into the slots of the frame.



2. Place the lower rod under the plastic clips (2) and clip into place. Be careful not to snap off the plastic clips.