


YOUR CURRENT VEHICLE  
**2018 Chrysler Pacifica**

-  Listen
-  Dictionary
-  Translate

## Removal & Installation

### REMOVAL AND INSTALLATION

#### REMOVAL




1. Remove the steering column lower shroud ([Refer to 19 - Steering/Column/SHROUD, Steering Column, Lower/Removal and Installation](#)).
2. Remove the steering column opening cover ([Refer to Body/Instrument Panel/COVER, Steering Column Opening/Removal and Installation](#)).
3. Remove the screw located in the media hub bezel opening (3).
4. Open the bin (2) and using a trim stick remove the media hub bezel (3) and set aside.
5. Remove the instrument cluster bezel ([Refer to 23 - Body/Instrument Panel/BEZEL, Instrument Cluster/Removal and Installation](#)).




6. Disconnect the electrical harness connector from the start stop switch (2).
7. Using a trim stick disengage the left side of the instrument panel center trim piece (1) to gain clearance to remove the gap hider.
8. Disengage the retaining clips from the gap hider (3) to the instrument panel, and remove.

#### INSTALLATION



1. Align the gap filler (3) and engage the retaining clips into the instrument panel.
2. Position the instrument panel center trim (1) and engage the retaining clips.
3. Connect the electrical harness connector to the start stop switch (2).



4. Position the media hub bezel (3) and engage the retaining clips.
5. Install the screw located in the media hub bezel opening, and tighten securely.
6. Install the instrument cluster bezel ([Refer to 23 - Body/Instrument Panel/BEZEL, Instrument Cluster/Removal and Installation](#)).
7. Install the steering column lower shroud ([Refer to Steering/Column/SHROUD, Steering Column, Lower/Removal and Installation](#)).
8. Install the steering column opening cover ([Refer to Body/Instrument Panel/COVER, Steering Column Opening/Removal and Installation](#)).