












Title			
AUAV-X21-V2 FMU+FLASH+uSD+USB			
Size	Number	Revision	
A4	June-11-2017-1600	R1	
Date:	11/10/2017	Sheet of	1/5
File:	C:\Users\AUAV_X21 FMU V2 R01\Documents	By:	NICK ARSOV




Title				AUAV-X21-V2 PORTs (SERIAL AND OTHER)			
Size		Number				Revision	
A4		June-11-2017-1600				R1	
Date:	11/10/2017					Sheet of 2/5	
File:	C:\Users\AUAV\X21 UARTS V2 R01					Sched By: NICK ARSOV	



TPS2062 EN is active LOW, while TPS2066 EN is active HIGH !!!



Title			
AUAV-X21-V2 POWER			
Size	Number	Revision	
A4	June-11-2017-1600	R1	
Date:	11/10/2017	Sheet of	3/5
File:	C:\Users\AUAV X21 POWER V2 R01\Drawings	Drawn By:	NICK ARSOV



Title			
AUAV-X21-V2 SENSORS			
Size	Number	Revision	
A4	June-11-2017-1600	R1	
Date:	11/10/2017	Sheet of	4/5
File:	C:\Users\AUAV_X21 SENSORS V2	Drawn by	NICK ARSOV

