





1. Please open the software of the Makerware , and choose this model:



2. Pls set PLA's printing parameters of the right extruder:



3. At last , click the export to Confirm generate the file

4. If you want to print with left extruder , please choose like this :

