




IOT-902

STATE MACHINE

SENDER & RECEIVER


OVERVIEW

SENDER STATES MACHINE






OVERVIEW

RECEIVER STATES MACHINE



LEGEND

-  **USUAL**
-  **ERROR**
-  **FIRST STATE**