








CORRECT POSITIONING OF VENT PCB,
POWER PCB, AND WIRES.



MOLEX ON THIS SIDE
OF BATTERY BOARD



INSTALLED VENT BOARD ORIENTATION.
NOTE RESET BUTTON LOCATION.



GENERAL NOTES

- SEE ARENA PLM FOR PART NUMBER REFERENCE DESIGNATORS AND CURRENT REVISIONS.
- ♦ CALLOUTS ARE APPLIED TO TOLERANCES THAT MAY REQUIRE SPECIAL QUALITY CONTROL PROCESSES. QUALITY CONTROL INSTRUCTIONS ARE OUTSIDE THE SCOPE OF THIS DRAWING AND ARE DEFINED BY EXTERNAL DOCUMENTATION TO BE AGREED TO WITH THE MANUFACTURER.
- ALL DIMENSIONS AND TOLERANCES MUST BE HELD REGARDLESS OF THE USE OF QUALITY CONTROL SYMBOLS.
- (X.XX) DIMENSIONS ARE USED AS REFERENCE ONLY AND ARE NOT SUBJECT TO TOLERANCES.
- UNLESS OTHERWISE SPECIFIED, ALL DIMENSIONS AND TOLERANCES ARE APPLICABLE AT 20 DEGREES CELSIUS (68 DEGREES FAHRENHEIT) IN ACCORDANCE WITH ANSI/ASME B89.6.2.
- ALL HOMOGENEOUS MATERIALS AND PROCESSES IN THIS DRAWING SHALL BE COMPLIANT TO THE EU ROHS DIRECTIVE 2011/65/EC.
- REFER TO DETAILED WORK INSTRUCTIONS FOR ASSEMBLY SPECIFICATIONS SUCH AS SCREW TORQUE AND GLUE VOLUME.

ASSEMBLY OVERVIEW:
(FOR REFERENCE ONLY. REFER TO DETAILED WORK INSTRUCTIONS FOR PRODUCTION ASSEMBLY INSTRUCTIONS)

- REMOVE THE MAGNETIC FACEPLATE COVER.
- REMOVE THE VENT BOARD COVER FROM THE BALLJOINT FACEPLATE.
- ATTACH THE BATTERY POWER CABLE TO THE BATTERY PCA.
- INSERT THE BATTERY PCA AS SHOWN. ENSURE SNAPS ARE FULLY ENGAGED. ENSURE WIRES ARE ROUTED BENEATH THE BOARD AS SHOWN.
- CONNECT THE THREE CABLE HARNESSSES TO THE VENT BOARD AS SHOWN. ENSURE THE MOLEX CONNECTORS ARE FULLY SEATED.
- PLACE THE VENT BOARD INTO POSITION AND SNAP THE VENT BOARD COVER ON TOP OF IT. ENSURE THE WIRES ARE NOT TANGLED OR DAMAGED, AND ARE HIDDEN UNDER THE BOARD.
- REMOVE TAPE AND REMOVE THE PRESSURE SENSOR COVER.
- ATTACH THE PRESSURE SENSOR BOARD TO THE PRESSURE SENSOR CABLE HARNESS. SEAT THE PRESSURE SENSOR IN POSITION ON THE MAIN BODY AS SHOWN.
- USE SCREWS TO ATTACH THE PRESSURE SENSOR COVER TO THE MAIN BODY WHERE SHOWN.
- APPLY 1 VENT ID LABEL CENTERED ON THE VENT BOARD COVER. ENSURE THAT LABEL IS ORIENTED AS SHOWN.
- APPLY 1 VENT ID LABEL ONTO THE MAIN BODY AS SHOWN. ENSURE THE LABEL EDGE IS ALIGNED WITH VERTICAL NOTCH.
- INSERT THE 4 BATTERIES INTO THE BATTERY PACK. USE THE POLARITY INDICATORS ON THE BATTERY PACK TO ENSURE CORRECT POLARITY.
- APPLY 2 ARROW STICKERS TO THE BATTERY PACK AS SHOWN.
- APPLY 1 ARROW STICKER TO THE BALLJOINT FACEPLATE AS SHOWN.
- REMOVE THE MAGNETIC FRAME.
- TORQUE THE M2 BALLJOINT SCREW TO TORQUE SPECIFIED IN THE DETAILED WORK INSTRUCTIONS.
- RE-ATTACH THE MAGNETIC FRAME.
- RE-ATTACH THE MAGNETIC FACEPLATE COVER.
- BAG THE #8X2 SCREWS AND #8 WASHERS AS SHOWN IN DETAILED WORK INSTRUCTIONS.
- THE ASSEMBLED BATTERY PACK AND BAGGED HARDWARE ARE SHIPPED ALONGSIDE THE VENT. DO NOT INSTALL THESE ITEMS.

DRAWING NO. 201-00015					DO NOT SCALE DRAWING. WORK TO DIMENSION						
REV	DESCRIPTION	ECO	DATE	BY	IF PLATING IS SPECIFIED, ALL DIMENSIONS TO BE MET AFTER PLATING						
A	INITIAL RELEASE (FROM 901-00015 DRAWING)	000082	2/25/16	AK	1. FERRITILE TO 0.15% 2. DIMENSIONS GIVEN IN INCHES						
B	DRAWING AND PART NUMBER UPDATE	DCO-000043	3/25/16	AK	CHAMF ANGLES=20° CONCENTRICITY=0.010 T.I.R.						
C	LABEL ORIENTATION	DCO-000044	3/29/16	AK	NOTICE: CHANGES TO MATERIAL, DESIGN, CONFIGURATION OR PROCESS MAY NOT BE MADE WITHOUT NOTIFICATION TO DC COVENANT. ALL MATERIALS AND PROCESSES MUST BE COMPLIANT WITH ENVIRONMENTAL LAWS AND REGULATIONS AS REFERENCED IN XXXXX						
MATERIAL:					DESIGN	CTG	CLASSIFICATION				
					★	★	(C)BAC				
					★	◆	HAKKID				
FINISH					REVIEW:		DATE:				
					TITLE: VENT 12X6 CEILING					A1	
					PART NO. 901-00015					SHEET 1 OF 1	
S/C# A1-3-1					THIS DOCUMENT IS THE PROPERTY OF ECOWING. NEITHER THIS DOCUMENT NOR ITS CONTENTS ARE TO BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING, RECORDING, OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM.						