



PERIPHOUT – Output from peripheral to master (output here)
MASTEROUT – Output from master to peripheral (input here)
SYNC/LOAD – display to outputs on falling edge
CLOCK – Change on rising edge, read on falling edge
Pull up DRV to find if that SAM is connected





Sheet: /Mounting/ File: Mounting.sch		
Title:		
Size: A4	Date:	Rev:
KiCad E.D.A. kicad (5.1.7)-1		Id: 2/3

