



Fnsn[AB]=Fader switch  
 Fnlnt[RGB]=Fader LED  
 FSS[MOSI/CLK/DCI/RS/CS]=VCC/GND=Scribble Strip  
 F[n+]=Fader  
 Ftn=Fader touch  
 FMOT[n+]=Fader motor

