

1 Comp. Loc. Vehicle Under Body

◆ ⇒ [“1.1 Exhaust 2.0l TDI CJAA”, page 1](#)

◆ ⇒ [“1.2 Exhaust 2.5l SRE CBTA/CBUA”, page 4](#)


1.1 Exhaust 2.0l TDI CJAA

◆ ⇒ [“1.1.1 Exhaust 2.0l TDI CJAA, I”, page 1](#)

◆ ⇒ [“1.1.2 Exhaust 2.0l TDI CJAA, II”, page 3](#)


1.1.1 Exhaust 2.0l TDI CJAA, I

- 1 - Exhaust pressure sensor 1 -G450-
- 2 - Differential pressure sensor -G505-
 - Exhaust pressure sensor 2 -G451-
- 3 - Exhaust gas temperature sensor 4 -G648-
- 4 - Exhaust door control unit -J883-
- 5 - Oxygen sensor after three way catalytic converter -G130-
- A - Double connector -T2at-
- B - 5-pin connector -T5ab-
- C - 6-pin connector -T6bb-



1.1.2 Exhaust 2.0I TDI CJAA, II

- 1 - Heated oxygen sensor -G39-
- 2 - Double connector -T2bb-
- 3 - Double connector -T2bz-
- 4 - Double connector -T2ba-
- 5 - 6-pin connector -T6w-
- 6 - Exhaust gas temperature sensor 1 -G235-
- 7 - Exhaust gas temperature sensor 2 -G448-
- 8 - Exhaust gas temperature sensor 3 -G495-



1.2 Exhaust 2.5I SRE CBTA/CBUA

- 1 - 6-pin connector -T6w-
- 2 - Heated oxygen sensor -G39-
- 3 - Oxygen sensor in bank 1 center three way catalytic converter -G465-
- 4 - Oxygen sensor after three way catalytic converter -G130-
- 5 - 4-pin connector -T4au-
- 6 - 4-pin connector -T4v-

