



NOTES:  
 \*OC = Outer coil terminal  
 \*IC = Inner coil terminal



5 Way Flex Switch Project by Cycfi Research is licensed under a Creative Commons Attribution-NonCommercial 4.0 International License. <http://creativecommons.org/licenses/by-nc/4.0/>

Copyright CYCFI Research Inc. 2013-2016

# CYCFI

TITLE: 5 Way Flex Switch



Document Number: 2016037

REV:  
v1.1

Date: 2/23/2016 2:32:06 PM

Sheet: 1/3

# OUTPUT HEADERS



5 Way Flex Switch Project by Cycfi Research is licensed under a Creative Commons Attribution-NonCommercial 4.0 International License. <http://creativecommons.org/licenses/by-nc/4.0/>

Copyright CYCFI Research Inc. 2013-2016

# CYCFI


TITLE: 5 Way Flex Switch

Document Number: 2016037


REV:  
v1.1

Date: 2/23/2016 2:32:06 PM

Sheet: 2/3



NOTES:  
 \*OC = Outer coil terminal  
 \*IC = Inner coil terminal



5 Way Flex Switch Project by Cycfi Research is licensed under a Creative Commons Attribution-NonCommercial 4.0 International License. <http://creativecommons.org/licenses/by-nc/4.0/>

Copyright CYCFI Research Inc. 2013-2016

# CYCFI

TITLE: Configuration Board

Document Number: 2016037

REV:  
v1.1

Date: 2/23/2016 2:32:06 PM

Sheet: 3/3