

#### CONTROL CONFIGURATION

1. 1 Volume - 1 Tone
  - \* PU1 = Shunt on pins 2&4
  - \* PU2 = Shunt on pins 1&3
2. 2 Tone - 1 Volume
  - \* PU1 = Shunt on pins 2&4;  
Insert tone control on pins 6&8
  - \* PU2 = Shunt on pins 1-3;  
Insert tone control on pins 5&7
3. 2 Volume - 2 Tone
  - \* PU1 = Insert volume control on pins 4-8
  - \* PU1 = Insert volume control on pins 3-7
  - \* Insert shunt on VOL header pins IN&OUT

| H2  |     |     |
|-----|-----|-----|
| PU2 | PIN | PU1 |
| OUT | 1 2 | OUT |
| IN  | 3 4 | IN  |
| OUT | 5 6 | OUT |
| GND | 7 8 | GND |

Toggle Switch Hub Project by Cycfi Research is licensed under a Creative Commons Attribution-ShareAlike 4.0 International License.

Copyright CYCFI Research Inc. 2013-2016

# CYCFI

**TITLE:** Toggle Switch Hub


**Document Number:** 2016038

**REV:**  
v1.1

**Date:** 12/5/2016 2:56:48 PM

**Sheet:** 1/2

# OUTPUT HEADERS



Toggle Switch Hub Project by Cycfi Research is licensed under a Creative Commons Attribution-ShareAlike 4.0 International License.

Copyright CYCFI Research Inc. 2013-2016

# CYCFI

**TITLE:** Toggle Switch Hub

**Document Number:** 2016038

**REV:**  
v1.1

**Date:** 12/5/2016 2:56:48 PM

**Sheet:** 2/2