



NOTES:
 *OC(C+) = Outer coil terminal
 *IC(C-) = Inner coil terminal



5 Way Flex Switch Project by Cycfi Research is licensed under a Creative Commons Attribution-NonCommercial 4.0 International License. <http://creativecommons.org/licenses/by-nc/4.0/>

Copyright CYCFI Research Inc. 2013-2016

CYCFI

TITLE: 5 Way Flex Switch



Document Number: 2016037

REV:
v1.1

Date: 2/18/2016 10:10:41 AM

Sheet: 1/3

OUTPUT HEADERS



5 Way Flex Switch Project by Cycfi Research is licensed under a Creative Commons Attribution-NonCommercial 4.0 International License. <http://creativecommons.org/licenses/by-nc/4.0/>

Copyright CYCFI Research Inc. 2013-2016

CYCFI

TITLE: 5 Way Flex Switch


Document Number: 2016037

REV:
v1.1

Date: 2/18/2016 10:10:41 AM


Sheet: 2/3

CONFIGURATION BOARD



NOTES:
 *OC<C+> = Outer coil terminal
 *IC<C-> = Inner coil terminal

PINOUT



5 Way Flex Switch Project by Cycfi Research is licensed under a Creative Commons Attribution-NonCommercial 4.0 International License. <http://creativecommons.org/licenses/by-nc/4.0/>

Copyright CYCFI Research Inc. 2013-2016

CYCFI

TITLE: 5 Way Flex Switch

Document Number: 2016037

REV:
v1.1

Date: 2/18/2016 10:10:41 AM

Sheet: 3/3