

RIGHT_POTENTIOMETER

1

Pocke

A

VDD :

C

I2C2_S

I2C2_S

B

SERV

C

USB1

USB1

V

D

AGND

LEFT_POTI

RIGHT_PO

E

Mechar



MGT1



MGT2




MC


1

tBeagle


B



Potentiometers




USB



Electricals





A

B

C

D

E

ENGI 301 - Combination Lock

etch-a-sketch

12/12/22 4:36 PM

Sheet:

Rev 1