


# REFERENCE VALUE

## ENGINE COMPARTMENT

(Three-Dimensional Distance)



Vehicle Dimensions

A - c or a - C	A - D or a - d	A - d or a - D	B - c or b - C	B - d or b - D	D - F or d - f
1,267 (49.88)	272 (10.71)	1,277 (50.28)	1,248 (49.13)	1,255 (49.41)	614 (24.17)

### HINT:

- 1) For symbols, capital letters indicate right side of vehicle, small letters indicate left side of vehicle (seen from rear).
- 2) These values are actual measurements made on model. Use these reference values.
- 3) Measure points with the radiator support upper seal and front fender upper protector removed.


mm (in.)

Symbol	Name	Hole dia.	D, d	Front fender installation bolt	—
A, a	Radiator grill installation screw	—	E, e	Front fender installation bolt	—
B, b	Headlight installation screw	—	F, f	Front fender installation bolt	—
C, c	Headlight installation screw	—	—	—	—

UNDER BODY

(Two-Dimensional Distance)

Front spring support



(Two-Dimensional Distance)

Rear shock absorber

AA - AA

