


F RELAY LOCATIONS

Junction Connector (CAN No. 2)	Cowl Side Panel RH (See Page 21)
--------------------------------	----------------------------------

(LHD)



Junction Connector (CAN No. 2) (RHD)	Cowl Side Panel LH (See Page 21)
---	----------------------------------

