



- E 1 Differential Lock Shift Actuator
- E 2 No. 1 Transfer Indicator Switch
  
- J 2 Outer Rear View Mirror Assembly RH
- J 3 Outer Rear View Mirror Assembly RH
- J 4 Front No. 2 Speaker Assembly RH
- J 5 Front Door Courtesy Light Assembly RH
- J 6 Front Door with Motor Lock Assembly RH
- J 7 Front Power Window Regulator Motor Assembly RH
- J 8 Side Airbag Sensor Assembly RH
- J 9 Multiplex Network Master Switch Assembly
- J 10 Seat Memory Switch
  
- K 1 Outer Rear View Mirror Assembly LH
- K 2 Outer Rear View Mirror Assembly LH
- K 3 Front No. 2 Speaker Assembly LH
- K 5 Front Door Courtesy Light Assembly LH
- K 6 Front Door with Motor Lock Assembly LH
- K 7 Front Power Window Regulator Motor Assembly LH
- K 8 Side Airbag Sensor Assembly LH
- K 10 Front Power Window Regulator Switch Assembly LH
  
- N 1 Electrical Key Antenna RH
  
- O 1 Electrical Key Antenna LH
  
- P 1 Front Side Step Light LH
- P 2 Front Side Step Light RH

# Position of Parts in Body <RHD 3-Door>

