

### Battery Charger

### Power switch control

### 3.3V converter

### I2C adapter output

### USB

### ZigBee

### Flash Memory

### MCU

### Air Temperature Sensor

### Screen

### GPS

IMPORTANT: SPI\_MISO line is always driven! requires additional hardware (see page 32 of manual)