



PWR = VALVE DRIVES
 AIN = TEMP SENSORS
 FREQ = SPEED SENSORS
 +12V = EXTERNAL 12V VALVE SUPPLY
 +5V FROM TCU

| | | |
|---------------------------------------|-------|---------|
| Sheet: / | | |
| File: TCU_Adapter_Board.kicad_sch | | |
| Title: TCU External Adapter V1 | | |
| Size: A4 | Date: | Rev: |
| KiCad E.D.A. 8.0.4 | | Id: 1/1 |