

**Westport Slough (OR)****LCR-43.2L**

**Position - Location:** 46° 8.622', -123° 23.004' 46° 8' 37.3", -123° 23' .3" 46.14370, -123.38341 Clatskanie

**Strategy Objective:** Collection, Exclusion : Collect oil and prevent it from entering Westport Slough.

**Implementation:** Only deploy strategy if ferry route has been shut down. Launch boat from Westport Boat Ramp, BL-LCR-43.8L, with 800ft. boom. Deploy boom just behind daymarker 58 over to pilings or trees on the west bank in a chevron configuration. Anchor to AP-1 and AP-2 using shoreside anchor posts, and to AP-3 using Danforth or other anchor. Anchor along boom length as necessary for conditions. If oil is travelling downstream (northward) on slough, angle boom upstream and anchor southeast of AP-2 and collect oil on eastern bank.

**Staging Area:** Remote: Stage at Westport Boat Ramp, SA-LCR-43.8L

**Site Safety:** Slips, trips, and falls. Water hazards. Active ferry route.

**Field Notes:** Site is at mouth of Westport Slough along active ferry route for Cathlamet-Westport ferry.

**Watercourse:** Slough - Westport Slough

**Resources at Risk:** Salmonid Concentrations and Habitat

**Recommended Equipment**

7	Each	Anchor - Danforth (or other appropriate type)
2	Each	Anchoring System(s)- Shoreside
800	Feet	Boom - B3 (River Boom) or equivalent
1	Each	Skimmer (appropriately sized) with Portable Storage
1	Each	Workboat(s) - of adequate size for type and amount of boom

**Recommended Personnel**

1	Boat Operator
3	Laborer
1	Supervisor